

## 8W-43 AIRBAG SYSTEM

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Airbag-Driver Squib 2 . . . . .	8W-43-4	Seat Belt-Tensioner-Driver . . . . .	8W-43-3
Airbag-Passenger Squib . . . . .	8W-43-4	Seat Belt-Tensioner-Passenger . . . . .	8W-43-3
Airbag-Side Curtain-Left . . . . .	8W-43-2	Sensor-Front Impact-Left . . . . .	8W-43-4
Airbag-Side Curtain-Right . . . . .	8W-43-2	Sensor-Front Impact-Right . . . . .	8W-43-4
Clockspring . . . . .	8W-43-4	Sensor-Seat Track Position-Driver . . . . .	8W-43-6
Fuse 16 . . . . .	8W-43-2, 6	Sensor-Seat Weight-Left Front . . . . .	8W-43-7
Fuse 25 . . . . .	8W-43-2	Sensor-Seat Weight-Left Rear . . . . .	8W-43-7
Fuse 33 . . . . .	8W-43-6	Sensor-Seat Weight-Right Front . . . . .	8W-43-7
G201 . . . . .	8W-43-2	Sensor-Seat Weight-Right Rear . . . . .	8W-43-7
G306 . . . . .	8W-43-6	Sensor-Side Impact-Left 1 . . . . .	8W-43-5
Junction Block . . . . .	8W-43-2, 6	Sensor-Side Impact-Left 2 . . . . .	8W-43-5
Lamp-Passenger Airbag On/Off Indicator . .	8W-43-2	Sensor-Side Impact-Left 3 . . . . .	8W-43-5
Module-Front Control . . . . .	8W-43-2, 6	Sensor-Side Impact-Right 1 . . . . .	8W-43-5
Module-Occupant Classification . . . . .	8W-43-6, 7	Sensor-Side Impact-Right 2 . . . . .	8W-43-5
Module-Occupant Restraint Controller . . . . .	8W-43-2, 3, 4, 5	Sensor-Side Impact-Right 3 . . . . .	8W-43-5













