

8W-56 CONVENIENCE SYSTEMS

Component	Page	Component	Page
Fuse 14	8W-56-3	Motor-Adjustable Pedals	8W-56-2, 3
G208	8W-56-2, 3	Power Distribution Center	8W-56-2
Junction Block	8W-56-2, 3	Relay-Adjustable Pedals	8W-56-3
Module-Front Control	8W-56-3	Sensor-Adjustable Pedals	8W-56-2
Module-Integrated Power	8W-56-3	Switch-Adjustable Pedals	8W-56-2, 3
Module-Seat Memory	8W-56-2		





