





8W-31 TRANSMISSION CONTROL SYSTEM

Component	Page	Component	Page
Assembly-Shift Motor/Mode Sensor	8W-31-6	Module-Powertrain	
Assembly-Transmission Solenoid/		Control	8W-31-2, 3, 4, 5, 7, 8, 9, 10, 11
Pressure Switch	8W-31-2, 7	Power Distribution Center	8W-31-2
Assembly-Transmission Solenoid/		Relay-Transmission Control	8W-31-2, 3, 4, 7, 9
TRS	8W-31-2, 3, 4, 5	Sensor-Input Speed	8W-31-11
Cluster	8W-31-10	Sensor-Line Pressure	8W-31-5
Fuse 19	8W-31-2, 10	Sensor-Output Speed	8W-31-11
G100	8W-31-11	Sensor-Transmission Range	8W-31-8
G113	8W-31-2	Solenoid-Brake Transmission Shift	
G208	8W-31-10	Interlock	8W-31-10
Junction Block	8W-31-10	Switch-Tow/Haul Overdrive	8W-31-10
Module-Front Control	8W-31-6	Switch-Transfer Case Selector	8W-31-10
Module-Integrated Power	8W-31-6		











4.7L/5.7L



3.7L



3.7L

