





8W-30 FUEL/IGNITION SYSTEM


Component	Page	Component	Page
Assembly-Natural Vacuum Leak		Motor-IAC	8W-30-17
Detection	8W-30-15	Power Distribution Center	8W-30-2, 3, 6
Assembly-Transmission Solenoid/TRS	8W-30-25	Relay-A/C Clutch	8W-30-23
Capacitor-Ignition	8W-30-7, 11	Relay-Auto Shut Down	8W-30-6, 7
Clockspring	8W-30-24	Relay-Fuel Pump	8W-30-3
Cluster	8W-30-4	Relay-Radiator Fan High	8W-30-5
Coil-Ignition-No. 1	8W-30-9, 12	Relay-Radiator Fan Low	8W-30-5
Coil-Ignition-No. 2	8W-30-9, 11	Relay-Starter Motor	8W-30-25
Coil-Ignition-No. 3	8W-30-9, 12	Resistor-Radiator Fan	8W-30-5
Coil-Ignition-No. 4	8W-30-9, 10, 11	Sensor-Accelerator Pedal Position	8W-30-23
Coil-Ignition-No. 5	8W-30-9, 12	Sensor-Camshaft Position	8W-30-15
Coil-Ignition-No. 6	8W-30-10, 11	Sensor-Crankshaft Position	8W-30-15
Coil-Ignition-No. 7	8W-30-9, 12	Sensor-Engine Coolant Temperature	8W-30-17, 18
Coil-Ignition-No. 8	8W-30-10, 11	Sensor-Engine Oil Temperature	8W-30-21
Data Link Connector	8W-30-13	Sensor-Intake Air Temperature	8W-30-17, 18
Fan Module-Condenser Cooling	8W-30-5	Sensor-Knock	8W-30-17
Fuse 10	8W-30-6	Sensor-Knock No. 1	8W-30-19
Fuse 16	8W-30-2	Sensor-Knock No. 2	8W-30-19
Fuse 18	8W-30-2, 3, 23	Sensor-MAP	8W-30-16, 18
Fuse 22	8W-30-2, 6	Sensor-Oil Pressure	8W-30-21
Fuse 23	8W-30-5	Sensor-Oxygen-Left Front	8W-30-14
Fuse 34	8W-30-2	Sensor-Oxygen-Left Rear	8W-30-14
G100	8W-30-2, 14, 18, 20	Sensor-Oxygen-Right Front	8W-30-14
G112	8W-30-5	Sensor-Oxygen-Right Rear	8W-30-14
G114	8W-30-4, 15	Sensor-Throttle Position	8W-30-16
Generator	8W-30-15	Sensor-Transmission Range	8W-30-25
Injector-Fuel-No. 1	8W-30-7, 12	Servo-Speed Control	8W-30-25
Injector-Fuel-No. 2	8W-30-8, 11	Solenoid-EVAP/Purge	8W-30-3
Injector-Fuel-No. 3	8W-30-7, 12	Solenoid-Multi Displacement	
Injector-Fuel-No. 4	8W-30-7, 11	System Cyl 1	8W-30-20
Injector-Fuel-No. 5	8W-30-7, 12	Solenoid-Multi Displacement	
Injector-Fuel-No. 6	8W-30-8, 11	System Cyl 4	8W-30-20
Injector-Fuel-No. 7	8W-30-8, 12	Solenoid-Multi Displacement	
Injector-Fuel-No. 8	8W-30-7, 11	System Cyl 6	8W-30-20
Junction Block	8W-30-2, 3, 4, 13, 22, 23, 24	Solenoid-Multi Displacement	
Module-Antilock Brakes	8W-30-22	System Cyl 7	8W-30-20
Module-Front Control	8W-30-5, 13	Switch-Oil Pressure	8W-30-15
Module-Fuel Pump	8W-30-3, 4	Switch-Speed Control-Left	8W-30-24
Module-Integrated Power	8W-30-3, 5	Switch-Speed Control-Right	8W-30-24
Module-Powertrain Control	8W-30-2, 3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25	Switch-Stop Lamp	8W-30-22
		Throttle Body	8W-30-19















3.7L/4.7L















5.7L











*** 3.7L/4.7L
*** 5.7L





* 3.7L


** 4.7L





5.7L











*** 5.7L

*** 3.7L/4.7L

