

8W-21 STARTING SYSTEM

Component	Page	Component	Page
Fuse 1	8W-21-2	Module-Powertrain Control	8W-21-2
Fuse 16	8W-21-2	Power Distribution Center	8W-21-2
G110	8W-21-2	Relay-Starter Motor	8W-21-2
G111	8W-21-2	Starter	8W-21-2

