




8W-15 GROUND DISTRIBUTION


| Component | Page |
|--|------------------------------|
| A/C Compressor Clutch | 8W-15-2, 9 |
| A/C-Heater Control | 8W-15-10, 12 |
| Adjustable Pedals Switch | 8W-15-11 |
| Amplifier | 8W-15-27 |
| Anti-Lock Brake Module | 8W-15-2, 4 |
| Auto Temp Control | 8W-15-10 |
| Backup Lamp Switch | 8W-15-2, 4 |
| Battery | 8W-15-2, 3, 4 |
| Body Control Module | 8W-15-24 |
| Brake Fluid Level Switch | 8W-15-18 |
| Brake Lamp Switch | 8W-15-18 |
| Cabin Heater Assist | 8W-15-9 |
| CD Changer | 8W-15-13 |
| Center High Mounted Stop Lamp | 8W-15-30 |
| Clockspring | 8W-15-13 |
| Clutch Pedal Interlock Switch | 8W-15-18 |
| Clutch Pedal Upstop Switch | 8W-15-19 |
| Controller Anti-Lock Brake | 8W-15-2, 4 |
| Crank Case Ventilation Heater | 8W-15-9 |
| Crankshaft Position Sensor | 8W-15-4 |
| Data Link Connector | 8W-15-3, 4, 18 |
| Dosing Pump | 8W-15-9 |
| Driver Door Courtesy Lamp | 8W-15-15, 21 |
| Driver Door Lock Switch | 8W-15-15, 21 |
| Driver Heated Seat Cushion | 8W-15-17 |
| Driver Heated Seat Module | 8W-15-17 |
| Driver Power Seat Switch | 8W-15-17 |
| Driver Power Window Switch | 8W-15-15, 21 |
| DVD/CD Changer | 8W-15-11 |
| EGR Solenoid | 8W-15-3 |
| Engine Control Module | 8W-15-4 |
| Floor Console Lamp | 8W-15-28 |
| Floor Console Power Outlet | 8W-15-28 |
| Front Blower Module | 8W-15-12 |
| Front Cigar Lighter | 8W-15-10 |
| Front Control Module | 8W-15-2, 8, 9, 19 |
| Front Reading Lamps/Switch | 8W-15-22 |
| Fuel Heater | 8W-15-9 |
| Fuel Heater Relay | 8W-15-4 |
| Fuel Pump Module | 8W-15-28 |
| G100 | 8W-15-2, 4 |
| G101 | 8W-15-2, 4 |
| G102 | 8W-15-5, 6, 7 |
| G103 | 8W-15-9 |
| G200 | 8W-15-10, 11, 12 |
| G201 | 8W-15-13 |
| G202 | 8W-15-13 |
| G300 | 8W-15-12, 14, 16, 17, 18, 19 |
| G301 | 8W-15-20, 21, 22, 24, 25 |
| G302 | 8W-15-26, 27, 28 |
| G303 | 8W-15-28, 29, 30 |
| Generator | 8W-15-2 |
| Hands Free Module | 8W-15-11 |
| Headlamp Switch | 8W-15-10 |
| Headlamp Washer Pump Motor | 8W-15-7 |
| High Note Horn | 8W-15-6 |
| Hood Ajar Switch | 8W-15-19 |
| Instrument Cluster | 8W-15-10 |
| Instrument Panel Switch Bank | 8W-15-10 |
| Integrated Power Module | 8W-15-2, 3, 4, 8, 9, 19 |
| Left B-Pillar Switch | 8W-15-18 |
| Left Cinch/Release Motor | 8W-15-14 |
| Left Cylinder Lock Switch | 8W-15-15, 16 |
| Left Fog Lamp | 8W-15-6 |
| Left Front Door Ajar Switch | 8W-15-16 |
| Left Front Door Lock Motor/Ajar Switch | 8W-15-15, 16 |
| Left Front Park/Turn Signal Lamp | 8W-15-6 |
| Left Full Open Switch | 8W-15-14 |
| Left Headlamp | 8W-15-19 |
| Left Headlamp Leveling Motor | 8W-15-7 |
| Left High Beam Lamp | 8W-15-8, 19 |
| Left Liftgate Flood Lamp | 8W-15-29 |
| Left Low Beam Lamp | 8W-15-8, 19 |
| Left Mid Reading Lamp | 8W-15-23 |
| Left Park Lamp | 8W-15-8, 19 |
| Left Power Mirror | 8W-15-12 |
| Left Rear Lamp Assembly | 8W-15-28 |
| Left Rear Reading Lamp | 8W-15-23 |
| Left Sliding Door Control Module | 8W-15-14 |
| Left Sliding Door Latch Sensing Switch | 8W-15-14 |
| Left Sliding Door Lock Motor | 8W-15-14 |
| Left Sliding Door Lock Motor/Ajar Switch | 8W-15-14 |


| Component | Page |
|---|--------------|
| Left Sliding Door Motor | 8W-15-14 |
| Left Turn Signal Lamp | 8W-15-19 |
| Left Visor/Vanity Lamp | 8W-15-23 |
| License Lamp | 8W-15-26, 29 |
| Liftgate Ajar Switch | 8W-15-30 |
| Liftgate Cinch/Release Motor | 8W-15-26, 30 |
| Liftgate Right Pinch Sensor | 8W-15-26 |
| Memory Seat/Mirror/Adjustable Pedals Module | 8W-15-17 |
| Natural Vacuum Leak Detection Assembly | 8W-15-2, 3 |
| Occupant Classification Module | 8W-15-24 |
| Occupant Restraint Controller | 8W-15-13 |
| Overhead Console | 8W-15-22 |
| Oxygen Sensor 1/1 Upstream | 8W-15-3 |
| Oxygen Sensor 1/2 Downstream | 8W-15-3 |
| Park Assist Display | 8W-15-28 |
| Park Assist Module | 8W-15-28 |
| Passenger Door Courtesy Lamp | 8W-15-16, 21 |
| Passenger Door Lock Switch | 8W-15-16, 21 |
| Passenger Heated Seat Back | 8W-15-25 |
| Passenger Heated Seat Cushion | 8W-15-25 |
| Passenger Heated Seat Module | 8W-15-25 |
| Passenger Power Seat Switch | 8W-15-25 |
| Power Folding Mirror Switch | 8W-15-12 |
| Power Liftgate Module | 8W-15-26, 28 |
| Power Liftgate Motor | 8W-15-26 |
| Power Mirror Switch | 8W-15-12 |
| Power Outlet | 8W-15-10 |
| Power Window Switch | 8W-15-15 |
| Powertrain Control Module | 8W-15-3 |
| Radiator Fan No. 1 | 8W-15-5 |
| Radiator Fan No. 2 | 8W-15-5 |
| Radiator Fan Relay | 8W-15-5 |
| Radiator Fan Relay No. 3 | 8W-15-5 |
| Radio | 8W-15-13 |
| Rear Auto Temp Control Switch | 8W-15-18 |
| Rear Blower Front Control Switch | 8W-15-12 |
| Rear Blower Motor Power Module | 8W-15-28 |
| Rear Blower Rear Control Switch | 8W-15-18 |
| Rear Dome Lamp | 8W-15-22, 23 |
| Rear Power Outlet | 8W-15-28 |
| Rear View Mirror | 8W-15-11, 22 |
| Rear Window Defogger Grid | 8W-15-30 |
| Rear Wiper Motor | 8W-15-29 |
| Right B-Pillar Switch | 8W-15-24 |
| Right Cinch/Release Motor | 8W-15-20 |
| Right Cylinder Lock Switch | 8W-15-21 |
| Right Fog Lamp | 8W-15-6 |
| Right Front Door Ajar Switch | 8W-15-21 |
| Right Front Door Lock Motor/Ajar Switch | 8W-15-21 |
| Right Front Park/Turn Signal Lamp | 8W-15-6 |
| Right Full Open Switch | 8W-15-20 |
| Right Headlamp | 8W-15-19 |
| Right Headlamp Leveling Motor | 8W-15-7 |
| Right High Beam Lamp | 8W-15-8, 19 |
| Right Liftgate Flood Lamp | 8W-15-29 |
| Right Low Beam Lamp | 8W-15-8, 19 |
| Right Mid Reading Lamp | 8W-15-23 |
| Right Park Lamp | 8W-15-8, 19 |
| Right Power Mirror | 8W-15-11, 12 |
| Right Rear Lamp Assembly | 8W-15-27, 28 |
| Right Rear Reading Lamp | 8W-15-23 |
| Right Sliding Door Control Module | 8W-15-20 |
| Right Sliding Door Latch Sensing Switch | 8W-15-20 |
| Right Sliding Door Lock Motor | 8W-15-20 |
| Right Sliding Door Lock Motor/Ajar Switch | 8W-15-20 |
| Right Sliding Door Motor | 8W-15-20 |
| Right Turn Signal Lamp | 8W-15-19 |
| Right Visor/Vanity Lamp | 8W-15-23 |
| Sentry Key Remote Entry Module | 8W-15-11 |
| Siren | 8W-15-11 |
| Speed Control Servo | 8W-15-2 |
| Sunroof Module | 8W-15-27 |
| Sunroof Switch | 8W-15-23 |
| Thatcham Alarm Module | 8W-15-11 |
| Traction Control Switch | 8W-15-11 |
| Trailer Tow Connector | 8W-15-27 |
| Transmission Control Module | 8W-15-4 |
| Transmission Control Relay | 8W-15-3, 4 |
| Washer Fluid Level Switch | 8W-15-5 |
| Wiper Module | 8W-15-18 |



















RS


8W-15 GROUND DISTRIBUTION


8W - 15 - 9


DIESEL





















































▲ EXCEPT EXPORT
▲▲ EXPORT

