

## 8W-18 BUS COMMUNICATIONS

<b>Component</b>	<b>Page</b>
A/C-Heater Control . . . . .	8W-18-6
Amplifier . . . . .	8W-18-5
Anti-Lock Brake Module . . . . .	8W-18-3, 4
Auto Temp Control . . . . .	8W-18-6
Battery . . . . .	8W-18-2
Body Control Module . . . . .	8W-18-3, 4, 5
Cabin Heater Assist . . . . .	8W-18-4
CD Changer . . . . .	8W-18-6
Controller Anti-Lock Brake . . . . .	8W-18-3, 4
Data Link Connector . . . . .	8W-18-2, 3, 4, 5
DVD/CD Changer . . . . .	8W-18-6
Engine Control Module . . . . .	8W-18-4
Front Control Module . . . . .	8W-18-3, 4, 5
G100 . . . . .	8W-18-2
G101 . . . . .	8W-18-2
G300 . . . . .	8W-18-2
Hands Free Module . . . . .	8W-18-6
Instrument Cluster . . . . .	8W-18-6

<b>Component</b>	<b>Page</b>
Integrated Power Module . . . . .	8W-18-2, 3, 4, 5
Left Sliding Door Control Module . . . . .	8W-18-5
Memory Seat/Mirror/Adjustable Pedals Module . . . . .	8W-18-5
Occupant Classification Module . . . . .	8W-18-5
Occupant Restraint Controller . . . . .	8W-18-6
Overhead Console . . . . .	8W-18-5
Park Assist Module . . . . .	8W-18-5
Power Liftgate Module . . . . .	8W-18-5
Powertrain Control Module . . . . .	8W-18-3
PTC 7 . . . . .	8W-18-2
Radio . . . . .	8W-18-6
Right Sliding Door Control Module . . . . .	8W-18-5
Sentry Key Remote Entry Module . . . . .	8W-18-6
Thatcham Alarm Module . . . . .	8W-18-3, 4, 6
Transmission Control Module . . . . .	8W-18-4









