




## 8W-30 FUEL/IGNITION SYSTEM

<b>Component</b>	<b>Page</b>
A/C Compressor Clutch . . . . .	8W-30-20
A/C Compressor Clutch Relay . . . . .	8W-30-4, 20
A/C Pressure Sensor . . . . .	8W-30-13, 18, 27
Accelerator Pedal Position Sensor . . . .	8W-30-32, 34
Ambient Temperature Sensor . . . . .	8W-30-8
Auto Shut Down Relay . . . .	8W-30-4, 11, 14, 16, 19
Battery . . . . .	8W-30-2, 6, 10, 15, 20, 28
Battery Temperature Sensor . . . . .	8W-30-27
Body Control Module . . . . .	8W-30-5, 21
Boost Pressure Sensor . . . . .	8W-30-27
Brake Lamp Switch . . . . .	8W-30-7, 23, 33
Cabin Heater Assist . . . . .	8W-30-24
Camshaft Position Sensor . . . . .	8W-30-8, 26
Clockspring . . . . .	8W-30-5, 25, 32
Clutch Pedal Interlock Switch . . . . .	8W-30-7
Clutch Pedal Upstop Switch . . . . .	8W-30-32
Crank Case Ventilation Heater . . . . .	8W-30-21
Crankshaft Position Sensor . . . . .	8W-30-12, 17, 26
Data Link Connector . . . . .	8W-30-3, 24
Dosing Pump . . . . .	8W-30-24
ECM/PCM Relay . . . . .	8W-30-20, 22, 26, 28, 30
EGR Solenoid . . . . .	8W-30-15, 30
Engine Control Module . . . .	8W-30-20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35
Engine Coolant Temp Sensor . . . .	8W-30-13, 18, 27
Engine Oil Pressure Sensor . . . . .	8W-30-23
Engine Oil Pressure Switch . . . . .	8W-30-7
EVAP/Purge Solenoid . . . . .	8W-30-4
Front Control Module . . . . .	8W-30-2, 5, 24, 32
Fuel Heater . . . . .	8W-30-21, 31
Fuel Heater Relay . . . . .	8W-30-21, 31
Fuel Injector No. 1 . . . . .	8W-30-14, 19, 29
Fuel Injector No. 2 . . . . .	8W-30-14, 19, 29
Fuel Injector No. 3 . . . . .	8W-30-14, 19, 29
Fuel Injector No. 4 . . . . .	8W-30-14, 19, 29
Fuel Injector No. 5 . . . . .	8W-30-19
Fuel Injector No. 6 . . . . .	8W-30-19
Fuel Pressure Sensor . . . . .	8W-30-33
Fuel Pressure Solenoid . . . . .	8W-30-22
Fuel Pump Module . . . . .	8W-30-5, 21
Fuel Pump Relay . . . . .	8W-30-5
Fuse 15 . . . . .	8W-30-24, 31
Fuse 16 . . . .	8W-30-4, 11, 14, 16, 19, 20, 22, 26, 28, 30
Fuse 17 . . . . .	8W-30-2, 5, 21, 31
Fuse 18 . . . . .	8W-30-20


<b>Component</b>	<b>Page</b>
Fuse 26 . . . . .	8W-30-33
Fusible Link . . . . .	8W-30-28
G100 . . . . .	8W-30-2, 6, 15, 21
G101 . . . . .	8W-30-2, 6, 7, 10, 15, 20
G103 . . . . .	8W-30-20, 21, 24, 31
G300 . . . . .	8W-30-7, 23, 32
G302 . . . . .	8W-30-5, 21
Generator . . . . .	8W-30-4, 21
Glow Plug No. 1 . . . . .	8W-30-28
Glow Plug No. 2 . . . . .	8W-30-28
Glow Plug No. 3 . . . . .	8W-30-28
Glow Plug No. 4 . . . . .	8W-30-28
Glow Plug Relay . . . . .	8W-30-28
Idle Air Control Motor . . . . .	8W-30-9
Ignition Coil . . . . .	8W-30-11, 16
Ignition Switch . . . . .	8W-30-10
Inlet Air Temperature Sensor . . . . .	8W-30-12, 17
Integrated Power Module . . . .	8W-30-2, 3, 4, 5, 10, 11, 14, 16, 19, 20, 21, 22, 24, 26, 28, 30, 31, 32, 33
Knock Sensor . . . . .	8W-30-9
Left Speed Control Switch . . . . .	8W-30-5, 25
Lift Pump Relay . . . . .	8W-30-31
Manifold Absolute Pressure Sensor . . .	8W-30-13, 18
Mass Air Flow Sensor . . . . .	8W-30-22
Natural Vacuum Leak Detection Assembly . . . . .	8W-30-10
Oxygen Sensor 1/1 Upstream . . . . .	8W-30-6
Oxygen Sensor 1/2 Downstream . . . . .	8W-30-6
Powertrain Control Module . . . .	8W-30-2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19
Radiator Fan Relay . . . . .	8W-30-11, 16
Radiator Fan Relay No. 1 . . . . .	8W-30-33
Radiator Fan Relay No. 2 . . . . .	8W-30-33
Radiator Fan Relay No. 3 . . . . .	8W-30-33
Right Speed Control Switch . . . . .	8W-30-5, 25
Speed Control Servo . . . . .	8W-30-7
Starter Motor Relay . . . . .	8W-30-5, 21
Throttle Position Sensor . . . . .	8W-30-12, 17
Transmission Control Module . . . .	8W-30-28, 32, 34, 35
Transmission Control Relay . . . . .	8W-30-28
Transmission Range Sensor . . . . .	8W-30-32
Vehicle Speed Sensor . . . . .	8W-30-9, 30
Water In Fuel Sensor . . . . .	8W-30-32










# GAS


















■ MTX













## 2.4L

































# DIESEL

