


## 8W-45 BODY CONTROL MODULE


<b>Component</b>	<b>Page</b>
A/C-Heater Control . . . . .	8W-45-16, 19
Anti-Lock Brake Module . . . . .	8W-45-13
Auto Temp Control . . . . .	8W-45-16, 19
Body Control Module . . . . .	8W-45-2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 19, 20
Clockspring . . . . .	8W-45-17
Controller Anti-Lock Brake . . . . .	8W-45-13
Driver Door Courtesy Lamp . . . . .	8W-45-15
Driver Door Lock Switch . . . . .	8W-45-12, 15
Driver Heated Seat Module . . . . .	8W-45-11
Floor Console Lamp . . . . .	8W-45-13
Front Control Module . . . . .	8W-45-3
Front Reading Lamps/Switch . . . . .	8W-45-13, 15
Fuel Pump Module . . . . .	8W-45-15
Fuse 14 . . . . .	8W-45-3
Fuse 19 . . . . .	8W-45-2
Fuse 24 . . . . .	8W-45-2
G301 . . . . .	8W-45-2, 8
Headlamp Switch . . . . .	8W-45-11, 16, 20
Hood Ajar Switch . . . . .	8W-45-12
Ignition Switch . . . . .	8W-45-3
Instrument Cluster . . . . .	8W-45-2, 16, 18, 19
Instrument Panel Switch Bank . . . . .	8W-45-10, 11, 17, 19
Integrated Power Module . . . . .	8W-45-2, 3, 5, 6, 13
Left B-Pillar Switch . . . . .	8W-45-9
Left Cylinder Lock Switch . . . . .	8W-45-10
Left Front Door Ajar Switch . . . . .	8W-45-9
Left Front Door Lock Motor/Ajar Switch . . . . .	8W-45-7, 9
Left Liftgate Flood Lamp . . . . .	8W-45-12
Left Mid Reading Lamp . . . . .	8W-45-9, 14
Left Power Mirror . . . . .	8W-45-20
Left Rear Lamp Assembly . . . . .	8W-45-5, 6
Left Rear Reading Lamp . . . . .	8W-45-9, 14
Left Remote Radio Switch . . . . .	8W-45-17
Left Repeater Lamp . . . . .	8W-45-20
Left Sliding Door Control Module . . . . .	8W-45-8, 10
Left Sliding Door Lock Motor . . . . .	8W-45-7
Left Sliding Door Lock Motor/Ajar Switch . . . . .	8W-45-7, 8
Left Visor/Vanity Lamp . . . . .	8W-45-13


<b>Component</b>	<b>Page</b>
License Lamp . . . . .	8W-45-8
Liftgate Ajar Switch . . . . .	8W-45-12
Liftgate Cinch/Release Motor . . . . .	8W-45-12
Memory Set Switch . . . . .	8W-45-4
Message Center . . . . .	8W-45-18
Multi-Function Switch . . . . .	8W-45-16
Overhead Console . . . . .	8W-45-4, 11
Passenger Door Courtesy Lamp . . . . .	8W-45-15
Passenger Door Lock Switch . . . . .	8W-45-12, 15
Passenger Folding Mirror Relay . . . . .	8W-45-20
Passenger Heated Seat Module . . . . .	8W-45-11
Power Folding Mirror Switch . . . . .	8W-45-20
Power Liftgate Module . . . . .	8W-45-8, 12
Radio . . . . .	8W-45-17
Rear Auto Temp Control Switch . . . . .	8W-45-10, 19
Rear Blower Rear Control Switch . . . . .	8W-45-10
Rear Dome Lamp . . . . .	8W-45-9
Rear View Mirror . . . . .	8W-45-11
Rear Wiper Motor . . . . .	8W-45-8
Right B-Pillar Switch . . . . .	8W-45-9
Right Cylinder Lock Switch . . . . .	8W-45-10
Right Front Door Ajar Switch . . . . .	8W-45-9
Right Front Door Lock Motor/Ajar Switch . . . . .	8W-45-7, 9
Right Liftgate Flood Lamp . . . . .	8W-45-12
Right Mid Reading Lamp . . . . .	8W-45-9, 14
Right Power Mirror . . . . .	8W-45-20
Right Rear Lamp Assembly . . . . .	8W-45-5, 6
Right Rear Reading Lamp . . . . .	8W-45-9, 14
Right Remote Radio Switch . . . . .	8W-45-17
Right Repeater Lamp . . . . .	8W-45-20
Right Sliding Door Control Module . . . . .	8W-45-8, 10
Right Sliding Door Lock Motor . . . . .	8W-45-7
Right Sliding Door Lock Motor/Ajar Switch . . . . .	8W-45-7, 8
Right Visor/Vanity Lamp . . . . .	8W-45-13
Sentry Key Remote Entry Module . . . . .	8W-45-3
Thatcham Alarm Module . . . . .	8W-45-10
Traction Control Switch . . . . .	8W-45-17
Trailer Tow Connector . . . . .	8W-45-5





























- ▲ HEATED SEATS
- ▲ EXCEPT EXPORT
- ▲▲ EXPORT
- ## EXCEPT HANDS FREE
- ▲▲▲▲ EXPORT EXCEPT HIGHLINE 3 ZONE



□ □ POWER RELEASE

• LHD  
•• RHD



◆◆◆ ABS

