




8W-63 POWER SEATS


Component	Page
Body Control Module	8W-63-5, 9
Driver Heated Seat Back	8W-63-9
Driver Heated Seat Cushion	8W-63-9
Driver Heated Seat Module	8W-63-3, 4, 9
Driver Power Seat Front Riser Motor . . .	8W-63-2, 7
Driver Power Seat Front Riser Position Sensor	8W-63-8
Driver Power Seat Horizontal Motor . . .	8W-63-2, 7
Driver Power Seat Horizontal Position Sensor	8W-63-8
Driver Power Seat Rear Riser Motor . . .	8W-63-2, 7
Driver Power Seat Rear Riser Position Sensor	8W-63-8
Driver Power Seat Recliner Motor	8W-63-2, 7
Driver Power Seat Recliner Position Sensor	8W-63-8
Driver Power Seat Switch	8W-63-2, 6
Front Control Module	8W-63-5
Fuse 22	8W-63-2, 4

Component	Page
G300	8W-63-2, 4, 6, 9
G301	8W-63-3, 10, 11
Instrument Panel Switch Bank	8W-63-9
Integrated Power Module	8W-63-2, 4, 5
Left Sliding Door Control Module	8W-63-5
Memory Seat/Mirror/Adjustable Pedals Module	8W-63-4, 5, 6, 7, 8
Memory Set Switch	8W-63-5
Passenger Heated Seat Back	8W-63-10, 11
Passenger Heated Seat Cushion	8W-63-10, 11
Passenger Heated Seat Module	8W-63-10, 11
Passenger Power Seat Front Riser Motor . .	8W-63-3
Passenger Power Seat Horizontal Motor . .	8W-63-3
Passenger Power Seat Rear Riser Motor . .	8W-63-3
Passenger Power Seat Recliner Motor . . .	8W-63-3
Passenger Power Seat Switch	8W-63-3
Power Seat Circuit Breaker	8W-63-2, 3, 4












▼▼▼ SIDE AIRBAG

▼▼▼▼ EXCEPT SIDE AIRBAG







- ▲ EXCEPT EXPORT
- ▲▲ EXPORT

