


Assembly – Transmission Solenoid/TRS (RFE)



ASSEMBLY-TRANSMISSION SOLENOID/TRS (RFE) - BLACK (TRANSMISSION) 23 WAY

CAV	CIRCUIT	FUNCTION
1	-	-
2	T20 20DG/WT	L/R SOLENOID CONTROL
3	-	-
4	T41 20YL/DB	TRS T41 SENSE
5	T42 20DG/YL	TRS T42 SENSE
6	-	-
7	T60 20YL/GY	OD SOLENOID CONTROL
8	T3 20DG/DB	TRS T3 SENSE
9	T1 20DG/LB	TRS T1 SENSE
10	T16 16YL/OR	TRANSMISSION CONTROL OUTPUT
11	T48 20BR/YL	4C PRESSURE SWITCH SENSE
12	T118 20DG	PRESSURE CONTROL SOLENOID CONTROL
13	T4 20DG/LB	TRS T2 SENSE
14	T50 20YL/TN	L/R PRESSURE SWITCH SENSE
15	T147 20DG/YL	2C PRESSURE SWITCH SENSE
16	T9 20DG/TN	OD PRESSURE SWITCH SENSE
17	T59 20YL/LB	UD SOLENOID CONTROL
18	T29 20YL/WT	UD PRESSURE SWITCH SENSE
19	T259 20YL/DG	4C SOLENOID CONTROL
20	T219 20YL/LG	2C SOLENOID CONTROL
21	T140 20YL/GY	MS SOLENOID CONTROL
22	K900 20DB/DG	SENSOR GROUND
22	T160 20DG/WT (DIESEL)	OD SOLENOID CONTROL
23	T54 20DG/OR	TRANSMISSION TEMPERATURE SENSOR SIGNAL