


Sensor – Crankcase (6.7L Diesel)



SENSOR-CRANKCASE (6.7L DIESEL) - (ENGINE) 3 WAY

CAV	CIRCUIT	FUNCTION
1	F855 18PK/YL	5 VOLT SUPPLY
2	K916 18BR/OR	SENSOR GROUND
3	K926 18DB/GY	CRANKCASE SENSOR SIGNAL

