



## 8W-15 GROUND DISTRIBUTION


Component	Page	Component	Page
Amplifier-Radio	8W-15-16	Media System-Monitor/Dvd	8W-15-16
Assembly-EGR Valve	8W-15-12	Mirror-Inside Rearview	8W-15-14
Assembly-Winch	8W-15-2	Mirror-Outside Rearview-Driver	8W-15-20
Auxiliary PDC Box	8W-15-5	Mirror-Outside Rearview-Passenger	8W-15-20
Backlite-Heated	8W-15-21	Module-Anti-Lock Brakes	8W-15-2, 6
Battery	8W-15-2	Module-Axle Disconnect-Front	8W-15-9
Battery-Auxiliary	8W-15-2	Module-Brake Provision	8W-15-9
Cluster	8W-15-15	Module-Electronic Overhead	8W-15-14
Clutch-A/C Compressor	8W-15-12, 13	Module-Engine Control	8W-15-13
Control-A/C-Heater	8W-15-14, 18	Module-Final Drive Control	8W-15-5
Data Link Connector	8W-15-14	Module-Fuel Pump	8W-15-8
G100	8W-15-2	Module-Hands Free	8W-15-16
G101	8W-15-2	Module-Occupant Restraint Controller	8W-15-19
G102	8W-15-2	Module-Powertrain Control	8W-15-12
G104	8W-15-2, 3, 4, 5, 6	Module-Sentry Key Remote Entry	8W-15-15
G105	8W-15-2	Module-Steering Control	8W-15-15
G106	8W-15-6, 7, 8, 9	Module-Totally Integrated Power	8W-15-2, 7, 10
G107	8W-15-10, 11, 12	Module-Transmission Control	8W-15-6
G111	8W-15-2	Motor-Condenser Fan	8W-15-9
G114	8W-15-13	Motor-Windshield Wiper	8W-15-6
G120	8W-15-13	Motor/Module-Sunroof	8W-15-17
G121	8W-15-13	Power Outlet	8W-15-18
G201	8W-15-14, 15	Power Outlet-Console	8W-15-19
G202	8W-15-16	Power Outlet-Instrument Panel	8W-15-18
G203	8W-15-17, 18	Power Outlet-Lower Console	8W-15-19
G301	8W-15-19	Pump-Washer-Windshield	8W-15-9
G302	8W-15-20	Radio	8W-15-16
G303	8W-15-21	Receiver-Satellite	8W-15-16
G304	8W-15-21	Relay-Intake Air Heater	8W-15-5
Generator	8W-15-13	Sensor-Brake Fluid Level	8W-15-4
Heater-Fuel	8W-15-13	Sensor-Dynamics	8W-15-15
Heater-Seat Cushion-Driver	8W-15-20	Sensor-Oxygen-Left Front	8W-15-11
Heater-Seat Cushion-Passenger	8W-15-20	Sensor-Oxygen-Left Rear	8W-15-11
Horn-No. 1	8W-15-7	Sensor-Oxygen-Right Front	8W-15-11
Horn-No. 2	8W-15-7	Sensor-Oxygen-Right Rear	8W-15-11
Lamp-Backup-Left	8W-15-3	Sensor-Steering Angle	8W-15-14
Lamp-Backup-Right	8W-15-8	Sensor-Transfer Case Position	8W-15-4, 12
Lamp-Bar-Tailgate	8W-15-3	Sensor-Transmission Range	8W-15-4
Lamp-Center Bezel	8W-15-18	Servo-Speed Control	8W-15-5
Lamp-Center Console	8W-15-19	Solenoid-Brake Transmission Shift Interlock	8W-15-17
Lamp-Clearance No. 1	8W-15-18	Solenoid-Multiple Displacement No. 1	8W-15-10
Lamp-Clearance No. 2	8W-15-18	Solenoid-Multiple Displacement No. 4	8W-15-10
Lamp-Clearance No. 3	8W-15-18	Solenoid-Multiple Displacement No. 6	8W-15-10
Lamp-Clearance No. 4	8W-15-18	Solenoid-Multiple Displacement No. 7	8W-15-10
Lamp-Clearance No. 5	8W-15-18	Switch-Adjustable Pedals	8W-15-18
Lamp-Dome-Rear	8W-15-17	Switch-Backup Lamp	8W-15-6, 10
Lamp-Fender-Front Left	8W-15-3	Switch-Clutch Interlock	8W-15-5
Lamp-Fender-Front Right	8W-15-3	Switch-Clutch Interlock/Upstop	8W-15-9
Lamp-Fender-Rear Left	8W-15-3	Switch-Disconnecting Stabilizer Bar	8W-15-5
Lamp-Fender-Rear Right	8W-15-3	Switch-Door Lock-Passenger	8W-15-21
Lamp-Fog-Left Front	8W-15-6	Switch-ESP	8W-15-14
Lamp-Fog-Right Front	8W-15-6	Switch-EVAP System Monitor	8W-15-5, 11
Lamp-Glove Box	8W-15-18	Switch-Exhaust Brake	8W-15-14
Lamp-Headlamp-Left	8W-15-4	Switch-Headlamp	8W-15-17
Lamp-Headlamp-Right	8W-15-7	Switch-Heated Seat-Driver	8W-15-15
Lamp-High Mounted Stop/Cargo	8W-15-17	Switch-Heated Seat-Passenger	8W-15-15
Lamp-License-Left	8W-15-3	Switch-Ignition	8W-15-15
Lamp-License-Right	8W-15-3	Switch-Power Sliding Backlite	8W-15-17
Lamp-Park-Left	8W-15-6	Switch-Seat Belt-Driver	8W-15-21
Lamp-Park-Right	8W-15-5	Switch-Seat-Driver	8W-15-20
Lamp-Park/Turn-Left Front	8W-15-7	Switch-Seat-Passenger	8W-15-20
Lamp-Park/Turn-Right Front	8W-15-4	Switch-Stop Lamp	8W-15-14
Lamp-Reading-Front	8W-15-17	Switch-Tow/Haul Overdrive	8W-15-14
Lamp-Tail Stop/Turn-Left	8W-15-3	Switch-Transfer Case Selector	8W-15-15
Lamp-Tail Stop/Turn-Right	8W-15-8	Switch-Window/Door Lock-Driver	8W-15-20
Lamp-Underhood	8W-15-4	Wiring-Trailer Tow	8W-15-8
Lamp-Vanity-Left	8W-15-17	Wiring-Trailer Tow 4-Way	8W-15-8
Lamp-Vanity-Right	8W-15-17	Wiring-Trailer Tow 7-Way	8W-15-8
Latch-Door-Driver	8W-15-21		
Latch-Door-Left Rear	8W-15-21		
Latch-Door-Passenger	8W-15-21		
Latch-Door-Right Rear	8W-15-21		




■ AWAL  
 ■ RWAL




 BOX ON  
 BOX OFF





■ M/T  
 ■ A/T  
 ○ DIESEL







■ AWAL  
 ○○ DIESEL














GAS

