


Sensor – Exhaust Outlet Temperature (Diesel)



**SENSOR-
EXHAUST
OUTLET
TEMPERATURE
(DIESEL)**

SENSOR-EXHAUST OUTLET TEMPERATURE (DIESEL) - (TRANSMISSION) 2 WAY

CAV	CIRCUIT	FUNCTION
1	K372 18BR/DG	EXHAUST OUTLET TEMPERATURE SENSOR SIGNAL
2	K900 18DB/DG	SENSOR GROUND

