

Sensor – Temperature/Pressure Intake (5.9L)




**SENSOR-
TEMPERATURE/
PRESSURE
INTAKE
(5.9L)**

SENSOR-TEMPERATURE/PRESSURE-INTAKE (5.9L) - (ENGINE) 4 WAY

CAV	CIRCUIT	FUNCTION
1	K690 18BR/YL	SENSOR GROUND
2	K615 18VT/WT	INLET AIR TEMPERATURE SENSE
3	K668 18BR	5 VOLT SUPPLY
4	K616 18BR/YL	INLET AIR PRESSURE SENSE

Sensor – Temperature/Pressure Intake (6.7L)



**SENSOR-
TEMPERATURE/
PRESSURE
INTAKE
(6.7L)**

SENSOR-TEMPERATURE/PRESSURE INTAKE (6.7L) - (ENGINE) 4 WAY

CAV	CIRCUIT	FUNCTION
1	K616 18BR/YL	INLET AIR PRESSURE SENSE
2	F855 18PK/YL	5 VOLT SUPPLY
3	K615 18VT/WT	INLET AIR TEMPERATURE SENSE
4	K916 18BR/OR	SENSOR GROUND