

## 8W-02 COMPONENT INDEX

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Actuator-Fuel Control . . . . .	8W-30	Lamps-License . . . . .	8W-51
Actuator-VGT . . . . .	8W-30	Lamps-Park . . . . .	8W-50
Actuators Door . . . . .	8W-42	Lamps-Park/Turn Front . . . . .	8W-50, 52
Airbags . . . . .	8W-43	Lamps-Tail Stop/Turn . . . . .	8W-51
Amplifier-Radio . . . . .	8W-47	Lamps-Vanity . . . . .	8W-44
Assembly-EGR Valve . . . . .	8W-30	Latches-Door . . . . .	8W-39, 61
Assembly-Line Pressure Sensor/Variable Force Solenoid . . . . .	8W-31	Media System-Monitor/DVD . . . . .	8W-47
Assembly-Shift Motor/Mode Sensor . . . . .	8W-31	Mirrors Rearview . . . . .	8W-55, 62
Assembly-Transmission Solenoid . . . . .	8W-31	Module-Anti-Lock Brakes . . . . .	8W-34, 35
Assembly-Transmission Solenoid/Pressure Switch . . . . .	8W-31	Module-Axle Disconnect-Front . . . . .	8W-31
Assembly-Transmission Solenoid/TRS . . . . .	8W-31	Module-Brake Provision . . . . .	8W-54
Assembly-Transmission Throttle Valve . . . . .	8W-31	Module-Electronic Overhead . . . . .	8W-49
Assembly-Winch . . . . .	8W-56	Module-Engine Control . . . . .	8W-30, 31
Auxiliary PDC Box . . . . .	8W-13	Module-Final Drive Control . . . . .	8W-31
Backlite-Heated . . . . .	8W-48	Module-Fuel Pump . . . . .	8W-30
Battery . . . . .	8W-13	Module-Hands Free . . . . .	8W-55
Battery-Auxiliary . . . . .	8W-13	Module-Occupant Restraint Controller . . . . .	8W-43
Capacitor-Ignition . . . . .	8W-30	Module-Powertrain Control . . . . .	8W-30, 31
Cluster . . . . .	8W-40	Module-Remote Throttle Provision . . . . .	8W-30
Clutch-A/C Compressor . . . . .	8W-42	Module-Sentry Key Remote Entry . . . . .	8W-39
Coils-Ignition . . . . .	8W-30	Module-Steering Control . . . . .	8W-33, 41, 43, 47
Control-A/C-Heater . . . . .	8W-42	Module-Totally Integrated Power . . . . .	8W-13
Data Link Connector . . . . .	8W-18	Module-Transmission Control . . . . .	8W-31
Drive-Fan-Radiator . . . . .	8W-30	Motor-Adjustable Pedals . . . . .	8W-56
Fuses . . . . .	8W-13	Motor-Blower . . . . .	8W-42
Fusible Link . . . . .	8W-13	Motor-Condenser Fan . . . . .	8W-42
Generator . . . . .	8W-20	Motor-IAC . . . . .	8W-30
Grounds . . . . .	8W-15	Motor-Power Sliding Backlite . . . . .	8W-60
Heater-Fuel . . . . .	8W-30	Motor-Windshield Wiper . . . . .	8W-53
Heater-Intake Air . . . . .	8W-30	Motor/Module-Sunroof . . . . .	8W-64
Heaters-Seat . . . . .	8W-63	Motors-Seat Adjusters . . . . .	8W-63
Horns . . . . .	8W-41	Motors-Windows . . . . .	8W-60
Injectors-Fuel . . . . .	8W-30	Port-Diagnostic . . . . .	8W-30
Lamp-Bar-Tailgate . . . . .	8W-51	Port-Upfitters . . . . .	8W-13, 30
Lamp-CHMSL-Aftermarket . . . . .	8W-51	Power Outlets . . . . .	8W-41
Lamp-Center Bezel . . . . .	8W-44	Pump-Washer-Windshield . . . . .	8W-53
Lamp-Center Console . . . . .	8W-44	Radio . . . . .	8W-47
Lamp-Clearances . . . . .	8W-50	Receiver-Satellite . . . . .	8W-47
Lamp-Dome-Rear . . . . .	8W-44	Relay-Intake Air Heater . . . . .	8W-30
Lamp-Glove Box . . . . .	8W-44	Relay-Turbo Shutdown . . . . .	8W-30
Lamp-High Mounted Stop/Cargo . . . . .	8W-51	Resistor-Blower Motor . . . . .	8W-42
Lamp-Reading-Front . . . . .	8W-44	Seat Belt-Tension Reducer-Driver . . . . .	8W-43
Lamp-Underhood . . . . .	8W-44	Seat Belt-Tensioners . . . . .	8W-43
Lamps-Backup . . . . .	8W-51	Sensor-Accelerator Pedal Position . . . . .	8W-30
Lamps-Fender . . . . .	8W-51	Sensor-Ambient Air Temperature . . . . .	8W-49
Lamps-Fog Front . . . . .	8W-50	Sensor-Battery Temperature . . . . .	8W-30
Lamps-Headlamp . . . . .	8W-50	Sensor-Brake Fluid Level . . . . .	8W-34, 35
		Sensor-Camshaft Position . . . . .	8W-30
		Sensor-Crankcase . . . . .	8W-30

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Sensor-Crankshaft Position . . . . .	8W-30	Speakers . . . . .	8W-47
Sensor-Dynamics . . . . .	8W-35	Splices . . . . .	8W-70
Sensor-EGR Orifice Temperature . . . . .	8W-30	Starter . . . . .	8W-21
Sensor-Engine Coolant Temperature . . . . .	8W-30	Switch-Adjustable Pedals . . . . .	8W-56
Sensor-Engine Oil Pressure . . . . .	8W-30	Switch-Backup Lamp . . . . .	8W-51
Sensor-Engine Oil Temperature . . . . .	8W-30	Switch-Clutch Interlock . . . . .	8W-30
Sensor-Evaporator Temperature . . . . .	8W-42	Switch-Clutch Interlock/Upstop . . . . .	8W-30
Sensor-Exhaust Outlet Temperature . . . . .	8W-30	Switch-Disconnecting Stabilizer Bar . . . . .	8W-31
Sensor-Exhaust Pressure . . . . .	8W-30	Switch-Door Lock-Passenger . . . . .	8W-61
Sensor-Fuel Rail Pressure . . . . .	8W-30	Switch-ESP . . . . .	8W-35
Sensor-Intake Air Temperature . . . . .	8W-30	Switch-EVAP System Monitor . . . . .	8W-30
Sensor-Knocks . . . . .	8W-30	Switch-Exhaust Brake . . . . .	8W-30
Sensor-Line Pressure . . . . .	8W-31	Switch-Headlamp . . . . .	8W-40
Sensor-MAP . . . . .	8W-30	Switch-Horn . . . . .	8W-41
Sensor-Mass Air Flow . . . . .	8W-30	Switch-Ignition . . . . .	8W-13
Sensor-Post Catalytic Temperature . . . . .	8W-30	Switch-Multifunction . . . . .	8W-40
Sensor-Pre-Catalytic Temperature . . . . .	8W-30	Switch-Oil Pressure . . . . .	8W-30
Sensor-Seat Track Position-Driver . . . . .	8W-43	Switch-PTO . . . . .	8W-30
Sensor-Soot Delta Pressure . . . . .	8W-30	Switch-Parking Brake . . . . .	8W-40
Sensor-Steering Angle . . . . .	8W-35	Switch-Passenger Airbag On/Off . . . . .	8W-43
Sensor-Temperature/Pressure-Intake . . . . .	8W-30	Switch-Power Sliding Backlite . . . . .	8W-60
Sensor-Temperature/Pressure-MAP . . . . .	8W-30	Switch-Seat Belt-Driver . . . . .	8W-43
Sensor-Throttle Position . . . . .	8W-30	Switch-Security Hood . . . . .	8W-21
Sensor-Transfer Case Position . . . . .	8W-31	Switch-Stop Lamp . . . . .	8W-33
Sensor-Transmission Range . . . . .	8W-31	Switch-Sunroof . . . . .	8W-64
Sensor-Transmission Temperature . . . . .	8W-31	Switch-Tow/Haul Overdrive . . . . .	8W-31
Sensor-Turbo Speed . . . . .	8W-30	Switch-Transfer Case Selector . . . . .	8W-31
Sensor-Water In Fuel . . . . .	8W-30	Switch-Washer Fluid Level . . . . .	8W-53
Sensors Impact . . . . .	8W-43	Switch-Winch . . . . .	8W-56
Sensors Speed . . . . .	8W-31	Switch-Window/Door Lock-Driver . . . . .	8W-60, 61, 62
Sensors-Oxygen . . . . .	8W-30	Switches-Heated Seat . . . . .	8W-63
Sensors-Prop Shaft Speed . . . . .	8W-31	Switches-Power Window . . . . .	8W-60
Sensors-Wheel Speed-ABS . . . . .	8W-34, 35	Switches-Remote Radio . . . . .	8W-47
Servo-Speed Control . . . . .	8W-33	Switches-Seat . . . . .	8W-63
Solenoid-Brake Transmission Shift Interlock . . . . .	8W-31	Switches-Speed Control . . . . .	8W-33
Solenoid-EVAP/Purge . . . . .	8W-30	Throttle Body . . . . .	8W-30
Solenoid-Multiple Displacements . . . . .	8W-30	Transducer-A/C Pressure . . . . .	8W-42
Solenoid-Wastegate . . . . .	8W-30	Wirings-Trailer Tow . . . . .	8W-54
Solenoids-Locker . . . . .	8W-31		