


Sensor – Transmission Range (RC)



**SENSOR-
TRANSMISSION
RANGE
(RC)**

SENSOR-TRANSMISSION RANGE (RC) - (TRANSMISSION) 10 WAY

CAV	CIRCUIT	FUNCTION
1	T825 20DG/YL	TRX-TRANS RANGE SW NEUTRAL
2	T3 20DG/DB	TRS T3 SENSE
3	T828 20DG/DB	TRX-TRANS RANGE SW 1
4	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (OFF-RUN-START)
5	T824 20YL/DB	TRX-TRANS RANGE SW PARK
6	Z157 16BK/LG	GROUND
7	T42 20DG/YL	TRS T42 SENSE
8	T827 20DG/LB	TRX-TRANS RANGE SW DRIVE
9	T826 20DG/DB	TRX-TRANS RANGE SW REVERSE
10	T41 20YL/DB	TRS T41 SENSE

