

## 8W-43 OCCUPANT RESTRAINT SYSTEM

<b>Component</b>	<b>Page</b>
Airbag-Driver Squib 1 . . . . .	8W-43-3
Airbag-Driver Squib 2 . . . . .	8W-43-3
Airbag-Passenger Squib . . . . .	8W-43-3
Airbag-Side Curtain-Left . . . . .	8W-43-4
Airbag-Side Curtain-Right . . . . .	8W-43-4
Cluster . . . . .	8W-43-4
Fuse 20 . . . . .	8W-43-2
Fuse 21 . . . . .	8W-43-2
Fuse 39 . . . . .	8W-43-4
G301 . . . . .	8W-43-2
G303 . . . . .	8W-43-4
Module-Occupant Restraint Controller . . . . .	8W-43-2, 3, 4, 5

<b>Component</b>	<b>Page</b>
Module-Steering Control . . . . .	8W-43-3
Module-Totally Integrated Power . . . .	8W-43-2, 4, 5
Seat Belt-Tension Reducer-Driver . . . . .	8W-43-4
Seat Belt-Tensioner-Driver . . . . .	8W-43-3
Seat Belt-Tensioner-Passenger . . . . .	8W-43-3
Sensor-Front Impact-Left . . . . .	8W-43-5
Sensor-Front Impact-Right . . . . .	8W-43-5
Sensor-Seat Track Position-Driver . . . . .	8W-43-5
Sensor-Side Impact-Left 1 . . . . .	8W-43-4
Sensor-Side Impact-Right 1 . . . . .	8W-43-4
Switch-Passenger Airbag On/Off . . . . .	8W-43-2
Switch-Seat Belt-Driver . . . . .	8W-43-4







