

8W-44 INTERIOR LIGHTING

Component	Page
Cluster	8W-44-2, 3, 4
Fuse 11	8W-44-3
Fuse 16	8W-44-3
G104	8W-44-3
G203	8W-44-2, 3
G302	8W-44-3
Lamp-Center Bezel	8W-44-3
Lamp-Center Console	8W-44-3
Lamp-Dome-Rear	8W-44-2
Lamp-Glove Box	8W-44-3
Lamp-High Mounted Stop/Cargo	8W-44-2
Lamp-Reading-Front	8W-44-2
Lamp-Underhood	8W-44-3

Component	Page
Lamp-Vanity-Left	8W-44-2
Lamp-Vanity-Right	8W-44-2
Latch-Door-Driver	8W-44-4
Latch-Door-Left Rear	8W-44-4
Latch-Door-Passenger	8W-44-4
Latch-Door-Right Rear	8W-44-4
Module-Totally Integrated Power	8W-44-3
Motor/Module-Sunroof	8W-44-2
Switch-Disconnecting Stabilizer Bar	8W-44-4
Switch-ESP	8W-44-4
Switch-Exhaust Brake	8W-44-4
Switch-Transfer Case Selector	8W-44-4





