




8W-40 INSTRUMENT CLUSTER


Component	Page
Amplifier-Radio	8W-40-9, 11
Clockspring	8W-40-5
Cluster	8W-40-2, 3, 4, 5, 6, 7, 8, 9, 11, 13
Control-A/C-Heater	8W-40-2, 3, 9, 11
Control-A/C-Heater-Rear	8W-40-4
Fuse 9	8W-40-2
Fuse 10	8W-40-2
Fuse 19	8W-40-3
Fuse 27	8W-40-2
G208	8W-40-2, 3, 13
G306	8W-40-3
Junction Block	8W-40-2, 3, 9, 10, 11, 12
Lamp-Center Bezel	8W-40-4
Lamp-Dome-Front	8W-40-8, 13
Lamp-Dome-Rear	8W-40-8, 13
Lamp-Liftgate	8W-40-8
Lamp-Reading-Front	8W-40-8, 13
Lamp-Vanity-Left	8W-40-13
Lamp-Vanity-Right	8W-40-13
Latch-Door-Left Front	8W-40-6
Latch-Door-Left Rear	8W-40-6
Latch-Door-Right Front	8W-40-6
Latch-Door-Right Rear	8W-40-6
Latch-Liftgate-Manual Release	8W-40-6
Latch-Power Liftgate	8W-40-7
Media System-Monitor/Dvd	8W-40-10, 12
Module-Clock-Analog	8W-40-2
Module-Door-Driver	8W-40-10, 12
Module-Door-Passenger	8W-40-10, 12
Module-Electronic Overhead	8W-40-10, 12


Component	Page
Module-Front Control	8W-40-10, 12
Module-Fuel Pump	8W-40-8
Module-Hands Free	8W-40-9, 11
Module-Heated Seat	8W-40-10, 12
Module-Occupant Restraint Controller	8W-40-9, 11
Module-Park Assist	8W-40-10, 12
Module-Power Liftgate	8W-40-10, 12
Module-Seat Memory	8W-40-10, 12
Module-Wireless Control	8W-40-9, 11
Radio	8W-40-9, 11
Receiver-Satellite	8W-40-10, 12
Sensor-Sun	8W-40-3
Solenoid-Brake Transmission Shift Interlock	8W-40-8
Switch And Lamp-Glove Box	8W-40-13
Switch-Headlamp	8W-40-13
Switch-Heated Seat-Driver	8W-40-4, 5
Switch-Heated Seat-Left Rear	8W-40-4
Switch-Heated Seat-Passenger	8W-40-4, 5
Switch-Heated Seat-Right Rear	8W-40-4
Switch-Horn	8W-40-5
Switch-Inverter	8W-40-13
Switch-Liftgate Ajar	8W-40-7
Switch-Multifunction	8W-40-5, 7
Switch-Parking Brake	8W-40-8
Switch-Remote Radio-Left	8W-40-5
Switch-Remote Radio-Right	8W-40-5
Switch-Seat Belt-Driver	8W-40-3
Switch-Traction Control	8W-40-8
Switch-Transfer Case Selector	8W-40-4, 7




















□ ATC
□ MTC

