

8W-42 AIR CONDITIONING/HEATER

| Component | Page |
|---|---------------|
| Actuator-Blend Door | 8W-42-3 |
| Actuator-Mode Door-Floor To Defrost | 8W-42-3 |
| Actuator-Mode Door-Floor To Panel | 8W-42-3 |
| Actuator-Recirculation Door | 8W-42-3 |
| Cluster | 8W-42-4 |
| Clutch-A/C Compressor | 8W-42-5 |
| Control-A/C-Heater | 8W-42-2, 3, 4 |
| Fuse 7 | 8W-42-5 |
| Fuse 11 | 8W-42-5 |
| Fuse 35 | 8W-42-4 |
| Fuse 59 | 8W-42-2 |
| G108 | 8W-42-5 |

| Component | Page |
|---|---------------|
| G200 | 8W-42-2 |
| G201 | 8W-42-2 |
| Module-Front Control | 8W-42-2, 4, 5 |
| Module-Integrated Power | 8W-42-2, 4, 5 |
| Module-Powertrain Control | 8W-42-5 |
| Motor-Blower | 8W-42-4 |
| Relay-A/C Clutch | 8W-42-5 |
| Relay-Blower Motor | 8W-42-4 |
| Resistor-Blower Motor | 8W-42-4 |
| Sensor-Evaporator Temperature | 8W-42-4 |
| Transducer-A/C Pressure | 8W-42-5 |







