




## 8W - 15 GROUND DISTRIBUTION


Component	Page	Component	Page
A/C Compressor Clutch . . . . .	8W-15-2, 9	Left Sliding Door Motor . . . . .	8W-15-14
A/C-Heater Control . . . . .	8W-15-10, 12	Left Turn Signal Lamp . . . . .	8W-15-19
Adjustable Pedals Switch . . . . .	8W-15-11	Left Visor/Vanity Lamp . . . . .	8W-15-23
Amplifier . . . . .	8W-15-27	License Lamp . . . . .	8W-15-26, 29
Anti-Lock Brake Module . . . . .	8W-15-2, 4	Liftgate Ajar Switch . . . . .	8W-15-30
Auto Temp Control . . . . .	8W-15-10	Liftgate Cinch/Release Motor . . . . .	8W-15-26, 30
Backup Lamp Switch . . . . .	8W-15-2, 4	Liftgate Right Pinch Sensor . . . . .	8W-15-26
Battery . . . . .	8W-15-2, 3, 4	Memory Seat/Mirror/Adjustable Pedals Module . . . . .	8W-15-17
Body Control Module . . . . .	8W-15-24	Natural Vacuum Leak Detection Assembly . . . . .	8W-15-2, 3
Brake Fluid Level Switch . . . . .	8W-15-18	Occupant Classification Module . . . . .	8W-15-24
Brake Lamp Switch . . . . .	8W-15-18	Occupant Restraint Controller . . . . .	8W-15-13
CD Changer . . . . .	8W-15-13	Overhead Console . . . . .	8W-15-22
Cabin Heater Assist . . . . .	8W-15-9	Oxygen Sensor 1/1 Upstream . . . . .	8W-15-3
Center High Mounted Stop Lamp . . . . .	8W-15-30	Oxygen Sensor 1/2 Downstream . . . . .	8W-15-3
Clockspring . . . . .	8W-15-13	Park Assist Display . . . . .	8W-15-28
Clutch Pedal Interlock Switch . . . . .	8W-15-18	Park Assist Module . . . . .	8W-15-28
Clutch Pedal Upstop Switch . . . . .	8W-15-19	Passenger Door Courtesy Lamp . . . . .	8W-15-16, 21
Controller Anti-Lock Brake . . . . .	8W-15-2, 4	Passenger Door Lock Switch . . . . .	8W-15-16, 21
Crank Case Ventilation Heater . . . . .	8W-15-9	Passenger Heated Seat Back . . . . .	8W-15-25
Crankshaft Position Sensor . . . . .	8W-15-4	Passenger Heated Seat Cushion . . . . .	8W-15-25
DVD/CD Changer . . . . .	8W-15-11	Passenger Heated Seat Module . . . . .	8W-15-25
Data Link Connector . . . . .	8W-15-3, 4, 18	Passenger Power Seat Switch . . . . .	8W-15-25
Dosing Pump . . . . .	8W-15-9	Power Folding Mirror Switch . . . . .	8W-15-12
Driver Door Courtesy Lamp . . . . .	8W-15-15, 21	Power Liftgate Module . . . . .	8W-15-26, 28
Driver Door Lock Switch . . . . .	8W-15-15, 21	Power Liftgate Motor . . . . .	8W-15-26
Driver Heated Seat Cushion . . . . .	8W-15-17	Power Mirror Switch . . . . .	8W-15-12
Driver Heated Seat Module . . . . .	8W-15-17	Power Outlet . . . . .	8W-15-10
Driver Power Seat Switch . . . . .	8W-15-17	Power Window Switch . . . . .	8W-15-15
Driver Power Window Switch . . . . .	8W-15-15, 21	Powertrain Control Module . . . . .	8W-15-3
EGR Solenoid . . . . .	8W-15-3	Radiator Fan No. 1 . . . . .	8W-15-5
Engine Control Module . . . . .	8W-15-4	Radiator Fan No. 2 . . . . .	8W-15-5
Floor Console Lamp . . . . .	8W-15-28	Radiator Fan Relay . . . . .	8W-15-5
Floor Console Power Outlet . . . . .	8W-15-28	Radiator Fan Relay No. 3 . . . . .	8W-15-5
Front Blower Module . . . . .	8W-15-12	Radio . . . . .	8W-15-13
Front Cigar Lighter . . . . .	8W-15-10	Rear Auto Temp Control Switch . . . . .	8W-15-18
Front Control Module . . . . .	8W-15-2, 8, 9, 19	Rear Blower Front Control Switch . . . . .	8W-15-12
Front Reading Lamps/Switch . . . . .	8W-15-22	Rear Blower Motor Power Module . . . . .	8W-15-28
Fuel Heater . . . . .	8W-15-9	Rear Blower Rear Control Switch . . . . .	8W-15-18
Fuel Heater Relay . . . . .	8W-15-4	Rear Dome Lamp . . . . .	8W-15-22, 23
Fuel Pump Module . . . . .	8W-15-28	Rear Power Outlet . . . . .	8W-15-28
G100 . . . . .	8W-15-2, 4	Rear View Mirror . . . . .	8W-15-11, 22
G101 . . . . .	8W-15-2, 4	Rear Window Defogger Grid . . . . .	8W-15-30
G102 . . . . .	8W-15-5, 6, 7	Rear Wiper Motor . . . . .	8W-15-29
G103 . . . . .	8W-15-9	Right B-Pillar Switch . . . . .	8W-15-24
G200 . . . . .	8W-15-10, 11, 12	Right Cinch/Release Motor . . . . .	8W-15-20
G201 . . . . .	8W-15-13	Right Cylinder Lock Switch . . . . .	8W-15-21
G202 . . . . .	8W-15-13	Right Fog Lamp . . . . .	8W-15-6
G300 . . . . .	8W-15-12, 14, 16, 17, 18, 19	Right Front Door Ajar Switch . . . . .	8W-15-21
G301 . . . . .	8W-15-20, 21, 22, 24, 25	Right Front Door Lock Motor/Ajar Switch . . . . .	8W-15-21
G302 . . . . .	8W-15-26, 27, 28	Right Front Park/Turn Signal Lamp . . . . .	8W-15-6
G303 . . . . .	8W-15-28, 29, 30	Right Full Open Switch . . . . .	8W-15-20
Generator . . . . .	8W-15-2	Right Headlamp . . . . .	8W-15-19
Hands Free Module . . . . .	8W-15-11	Right Headlamp Leveling Motor . . . . .	8W-15-7
Headlamp Switch . . . . .	8W-15-10	Right High Beam Lamp . . . . .	8W-15-8, 19
Headlamp Washer Pump Motor . . . . .	8W-15-7	Right Liftgate Flood Lamp . . . . .	8W-15-29
High Note Horn . . . . .	8W-15-6	Right Low Beam Lamp . . . . .	8W-15-8, 19
Hood Ajar Switch . . . . .	8W-15-19	Right Mid Reading Lamp . . . . .	8W-15-23
Instrument Cluster . . . . .	8W-15-10	Right Park Lamp . . . . .	8W-15-8, 19
Instrument Panel Switch Bank . . . . .	8W-15-10	Right Power Mirror . . . . .	8W-15-11, 12
Integrated Power Module . . . . .	8W-15-2, 3, 4, 8, 9, 19	Right Rear Lamp Assembly . . . . .	8W-15-27, 28
Left B-Pillar Switch . . . . .	8W-15-18	Right Rear Reading Lamp . . . . .	8W-15-23
Left Cinch/Release Motor . . . . .	8W-15-14	Right Sliding Door Control Module . . . . .	8W-15-20
Left Cylinder Lock Switch . . . . .	8W-15-15, 16	Right Sliding Door Latch Sensing Switch . . . . .	8W-15-20
Left Fog Lamp . . . . .	8W-15-6	Right Sliding Door Lock Motor . . . . .	8W-15-20
Left Front Door Ajar Switch . . . . .	8W-15-16	Right Sliding Door Lock Motor/Ajar Switch . . . . .	8W-15-20
Left Front Door Lock Motor/Ajar Switch . . . . .	8W-15-15, 16	Right Sliding Door Motor . . . . .	8W-15-20
Left Front Park/Turn Signal Lamp . . . . .	8W-15-6	Right Turn Signal Lamp . . . . .	8W-15-19
Left Full Open Switch . . . . .	8W-15-14	Right Visor/Vanity Lamp . . . . .	8W-15-23
Left Headlamp . . . . .	8W-15-19	Sentry Key Remote Entry Module . . . . .	8W-15-11
Left Headlamp Leveling Motor . . . . .	8W-15-7	Siren . . . . .	8W-15-11
Left High Beam Lamp . . . . .	8W-15-8, 19	Speed Control Servo . . . . .	8W-15-2
Left Liftgate Flood Lamp . . . . .	8W-15-29	Sunroof Module . . . . .	8W-15-27
Left Low Beam Lamp . . . . .	8W-15-8, 19	Sunroof Switch . . . . .	8W-15-23
Left Mid Reading Lamp . . . . .	8W-15-23	Thatcham Alarm Module . . . . .	8W-15-11
Left Park Lamp . . . . .	8W-15-8, 19	Traction Control Switch . . . . .	8W-15-11
Left Power Mirror . . . . .	8W-15-12	Trailer Tow Connector . . . . .	8W-15-27
Left Rear Lamp Assembly . . . . .	8W-15-28	Transmission Control Module . . . . .	8W-15-4
Left Rear Reading Lamp . . . . .	8W-15-23	Transmission Control Relay . . . . .	8W-15-3, 4
Left Sliding Door Control Module . . . . .	8W-15-14	Washer Fluid Level Switch . . . . .	8W-15-5
Left Sliding Door Latch Sensing Switch . . . . .	8W-15-14	Wiper Module . . . . .	8W-15-18
Left Sliding Door Lock Motor . . . . .	8W-15-14		
Left Sliding Door Lock Motor/Ajar Switch . . . . .	8W-15-14		








## DIESEL
















RS


8W-15 GROUND DISTRIBUTION  
DIESEL


8W - 15 - 9














▲▲ EXPORT  
□□□□ CD CHANGER











































- ▲ EXCEPT EXPORT
- ▲▲ EXPORT



