

8W-02 COMPONENT INDEX

Component	Page	Component	Page
Actuator-Blend Door	8W-42	Module-Electronic Overhead	8W-49
Actuator-Mode Door-Floor To Defrost	8W-42	Module-Front Control	8W-13
Actuator-Mode Door-Floor To Panel	8W-42	Module-Fuel Pump	8W-30
Actuator-Recirculation Door	8W-42	Module-Hands Free	8W-55
Airbag-Driver Squibs	8W-43	Module-Heated Seat	8W-63
Airbag-Passenger Squib	8W-43	Module-Integrated Power	8W-13
Airbag-Side Curtain-Left	8W-43	Module-Occupant Classification	8W-43
Airbag-Side Curtain-Right	8W-43	Module-Occupant Restraint Controller	8W-43
Amplifier-Radio	8W-47	Module-Powertrain Control	8W-30, 31
Antenna-Satellite	8W-47	Module-Sentry Key Remote Entry	8W-39
Assembly-Exhaust Gas Recirculation Valve	8W-30	Motor-Blower	8W-42
Assembly-Natural Vacuum Leak Detection	8W-30	Motor-IAC	8W-30
Assembly-Seat Motor	8W-63	Motors-Window	8W-60
Assembly-Shift Motor/Mode Sensor	8W-31	Motor-Windshield Wiper	8W-53
Assembly-Transmission Solenoid/Pressure Switch	8W-31	Power Outlets	8W-41
Assembly-Transmission Solenoid/TRS	8W-31	Pump-Washer-Windshield	8W-53
Backlite-Heated	8W-48	Radio	8W-47
Battery	8W-13	Receiver-Satellite	8W-47
Capacitor-Ignition	8W-30	Relay-A/C Clutch	8W-42
Circuit Breaker-Window/Door Lock	8W-13	Relay-Auto Shut Down	8W-30
Clockspring	8W-33, 40, 43, 47	Relay-Fog Lamp	8W-50
Cluster	8W-40	Relay-Fuel Pump	8W-30
Clutch-A/C Compressor	8W-42	Relay-Horn	8W-41
Coils-Ignition	8W-30	Relay-Park Lamp	8W-50, 51
Control-A/C-Heater	8W-42	Relay-Rear Window Defogger	8W-48
Data Link Connector	8W-18	Relay-Starter	8W-21
Diodes	8W-13	Relays-Wiper	8W-53
Fuses	8W-13	Relay-Trailer Tow-Left	8W-54
Fusible Link	8W-13	Relay-Trailer Tow-Right	8W-54
Generator	8W-20	Relay-Transmission Control	8W-31
Grounds	8W-15	Resistor-Blower Motor	8W-42
Heaters-Cushion Pad	8W-63	Seat Belt-Tensioners	8W-43
Horns	8W-41	Sensor-Ambient Air Temperature	8W-30
Injectors-Fuel	8W-30	Sensor-Battery Temperature	8W-13, 20
Lamp-Center Bezel	8W-44	Sensor-Brake Fluid Level	8W-34, 35
Lamp-High Mounted Stop	8W-51	Sensor-Camshaft Position	8W-30
Lamp-License-Left	8W-51	Sensor-Crankshaft Position	8W-30
Lamp-Passenger Airbag On/Off Indicator	8W-43	Sensor-Engine Coolant Temperature	8W-30
Lamps-Backup	8W-51, 54	Sensor-Evaporator Temperature	8W-42
Lamps-Dome	8W-44	Sensor-Intake Air Temperature	8W-30
Lamps-Fog	8W-50	Sensor-Knock	8W-30
Lamps-Headlamp	8W-50	Sensor-Line Pressure	8W-31
Lamps-Park/Turn	8W-50, 52	Sensor-MAP	8W-30
Lamps-Tail/Stop/Turn	8W-51, 52	Sensors-Front Impact	8W-43
Latches-Door	8W-61	Sensors-Oxygen	8W-30
Mirror-Inside Rearview	8W-49	Sensors-Seat Track Position	8W-43
Mirrors-Outside Rearview	8W-62	Sensors-Seat Weight	8W-43
Module-Anti-Lock Brakes	8W-34, 35	Sensors-Side Impact	8W-43
		Sensors-Speed	8W-31

Component	Page
Sensor-Sun	8W-40
Sensors-Wheel Speed-ABS	8W-35
Sensor-Throttle Position	8W-30
Sensor-Transmission Range	8W-31
Sensor-Washer Fluid Level-Front Rear	8W-53
Servo-Speed Control	8W-33
Solenoid-Brake Transmission Shift	8W-31
Solenoid-EVAP/Purge	8W-30
Speakers	8W-47
Splices	8W-70
Starter	8W-21
Switch And Lamp-Glove Box	8W-44
Switch-Back-Up Lamp	8W-31, 51
Switch-Clutch Interlock	8W-31
Switches-Heated Seat	8W-63
Switches-Power Window	8W-60
Switches-Remote Radio	8W-47
Switches-Speed Control	8W-33

Component	Page
Switches-Window/Door Lock	8W-60, 61
Switch-Headlamp	8W-44, 50
Switch-Horn	8W-41
Switch-Ignition	8W-13
Switch-Mirror	8W-62
Switch-Multifunction	8W-53
Switch-Oil Pressure	8W-30
Switch-Parking Brake	8W-40
Switch-Passenger Airbag On/Off	8W-43
Switch-Seat Belt-Driver	8W-43
Switch-Seat-Driver	8W-63
Switch-Stop Lamp	8W-51
Switch-Tow/Haul Overdrive Off	8W-31
Switch-Transfer Case Selector	8W-31
Transducer-A/C Pressure	8W-42
Wiring-Trailer Tow 4-Way	8W-54
Wiring-Trailer Tow 7-Way	8W-54
Wiring-Trailer Tow Electric Brake	8W-54