

## 8W-21 STARTING SYSTEM

<b>Component</b>	<b>Page</b>
Battery-Auxiliary . . . . .	8W-21-4
Cluster . . . . .	8W-21-3
Electronics . . . . .	8W-21-2, 3, 4
Fuse 10 . . . . .	8W-21-2, 4
G100 . . . . .	8W-21-3
G104 . . . . .	8W-21-2, 4
Module-Powertrain Control . . . . .	8W-21-2, 3
Module-Totally Integrated Power . . . .	8W-21-2, 3, 4

<b>Component</b>	<b>Page</b>
Relay-Starter . . . . .	8W-21-3
Relay-Starter Motor . . . . .	8W-21-2, 4
Sensor-Transmission Range . . . . .	8W-21-3, 4
Starter . . . . .	8W-21-2, 3, 4
Switch-Clutch Interlock . . . . .	8W-21-2, 3, 4
Switch-Ignition . . . . .	8W-21-2, 3, 4
Switch-Push-Button Starter . . . . .	8W-21-3





