

## 8W-02 COMPONENT INDEX

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Actuator-Fuel Control . . . . .	8W-30	Lamps-License . . . . .	8W-51
Actuator-Mode Doors . . . . .	8W-42	Lamps-Park/Turn . . . . .	8W-50, 52
Actuator-Recirculation Door . . . . .	8W-42	Lamps-Side Marker . . . . .	8W-50
Airbags . . . . .	8W-43	Lamps-Tail Stop/Turn . . . . .	8W-51
Amplifier-Radio . . . . .	8W-47	Lamps-Vanity . . . . .	8W-44
Amplifier-Subwoofer . . . . .	8W-47	Latches-Door . . . . .	8W-39, 61
Assembly-EGR Valve . . . . .	8W-30	Media System-Monitor/DVD . . . . .	8W-47
Assembly-Line Pressure Sensor/Variable Force Solenoid . . . . .	8W-31	Mirror-Inside Rearview . . . . .	8W-55
Assembly-Natural Vacuum Leak Detection . .	8W-30	Mirrors-Outside Rearview . . . . .	8W-62
Assembly-Shift Motor/Mode Sensor . . . . .	8W-31	Module-Anti-Lock Brakes . . . . .	8W-34, 35
Assembly-Transmission Solenoid . . . . .	8W-31	Module-Axle Disconnect-Front . . . . .	8W-31
Assembly-Transmission Solenoid/TRS . . . . .	8W-31	Module-Brake Provision . . . . .	8W-54
Assembly-Transmission Throttle Valve . . . . .	8W-31	Module-Electronic Overhead . . . . .	8W-49
Assembly-Winch . . . . .	8W-56	Module-Engine Control . . . . .	8W-30, 31
Backlite-Heated . . . . .	8W-48	Module-Final Drive Control . . . . .	8W-31
Battery . . . . .	8W-13	Module-Fuel Pump . . . . .	8W-30
Battery-Auxiliary . . . . .	8W-13	Module-Gateway . . . . .	8W-18
Capacitor-Ignition . . . . .	8W-30	Module-Hands Free . . . . .	8W-55
Clockspring . . . . .	8W-33, 41, 43, 47	Module-Occupant Restraint Controller . . . . .	8W-43
Cluster . . . . .	8W-40	Module-Powertrain Control . . . . .	8W-30, 31
Clutch-A/C Compressor . . . . .	8W-42	Module-Sentry Key Remote Entry . . . . .	8W-39
Coilc-Ignition . . . . .	8W-30	Module-Totally Integrated Power . . . . .	8W-13
Control-A/C-Heater . . . . .	8W-42	Motor-Adjustable Pedal . . . . .	8W-56
Data Link Connector . . . . .	8W-18	Motor-Blower . . . . .	8W-42
Drive-Fan-Radiator . . . . .	8W-30	Motor-Condenser Fan . . . . .	8W-42
Electronics . . . . .	8W-13	Motor-Power Sliding Backlite . . . . .	8W-60
Fuses . . . . .	8W-13	Motor-Windshield Wiper . . . . .	8W-53
Fusible Link . . . . .	8W-13	Motor/Module-Sunroof . . . . .	8W-64
Gauge-Engine Oil Temperature . . . . .	8W-40	Motors-IAC . . . . .	8W-30
Generator . . . . .	8W-20	Motors-Seat Adjuster . . . . .	8W-63
Grounds . . . . .	8W-15	Motors-Window . . . . .	8W-60
Heater-Fuel . . . . .	8W-30	Power Outlets . . . . .	8W-41
Heater-Intake Air . . . . .	8W-30	Pump-Fuel Injection . . . . .	8W-30
Heaters-Seat . . . . .	8W-63	Pump-Leak Detection . . . . .	8W-30
Horns . . . . .	8W-41	Pump-Washer-Windshield . . . . .	8W-53
Injectors-Fuels . . . . .	8W-30	Radio . . . . .	8W-47
Lamp-Bar-Tailgate . . . . .	8W-51	Receiver-Satellite . . . . .	8W-47
Lamp-CHMSL-Aftermarket . . . . .	8W-51	Relay-Intake Air Heater . . . . .	8W-30
Lamp-Center Bezel . . . . .	8W-44	Relay-Starter . . . . .	8W-21
Lamp-Clearances . . . . .	8W-50	Relay-Starter Motor . . . . .	8W-21
Lamp-Dome-Rear . . . . .	8W-44	Resistor Block-Blower Motor . . . . .	8W-42
Lamp-Glove Box . . . . .	8W-44	Seat Belt Tensioners . . . . .	8W-43
Lamp-High Mounted Stop/Cargo . . . . .	8W-51	Seat Belt-Tension Reducer-Driver . . . . .	8W-43
Lamp-Reading-Front . . . . .	8W-44	Sensor-Accelerator Pedal Position . . . . .	8W-30
Lamp-Underhood . . . . .	8W-44	Sensor-Ambient Air Temperature . . . . .	8W-49
Lamps-Fender . . . . .	8W-51	Sensor-Battery Temperature . . . . .	8W-30
Lamps-Fog . . . . .	8W-50	Sensor-Brake Fluid Level . . . . .	8W-34, 35
Lamps-Headlamps . . . . .	8W-50	Sensor-Camshaft Position . . . . .	8W-30
		Sensor-Crankshaft Position . . . . .	8W-30

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Sensor-Engine Coolant Temperature . . . . .	8W-30	Switch-Adjustable Pedals . . . . .	8W-56
Sensor-Engine Oil Pressure . . . . .	8W-30	Switch-Backup Lamp . . . . .	8W-51
Sensor-Engine Oil Temperature . . . . .	8W-30	Switch-Clutch Interlock . . . . .	8W-21
Sensor-Evaporator Temperature . . . . .	8W-42	Switch-Disconnecting Stabilizer Bar . . . . .	8W-31
Sensor-Input Speed . . . . .	8W-31	Switch-Door Lock-Passenger . . . . .	8W-61
Sensor-Intake Air Temperature . . . . .	8W-30	Switch-Headlamp . . . . .	8W-40
Sensor-Knocks . . . . .	8W-30	Switch-Horn . . . . .	8W-41
Sensor-Line Pressure . . . . .	8W-31	Switch-Ignition . . . . .	8W-13
Sensor-MAP . . . . .	8W-30	Switch-Multifunction . . . . .	8W-40
Sensor-Output Speed . . . . .	8W-31	Switch-Oil Pressure . . . . .	8W-30
Sensor-Seat Track Position-Driver . . . . .	8W-43	Switch-PTO . . . . .	8W-30
Sensor-Temperature/Pressure Intake . . . . .	8W-30	Switch-Parking Brake . . . . .	8W-40
Sensor-Temperature/Pressure-Map . . . . .	8W-30	Switch-Passenger Airbag On/Off . . . . .	8W-43
Sensor-Throttle Position . . . . .	8W-30	Switch-Power Sliding Backlite . . . . .	8W-60
Sensor-Transfer Case Position . . . . .	8W-31	Switch-Power Steering Pressure . . . . .	8W-30
Sensor-Transmission Range . . . . .	8W-31	Switch-Push-Button Starter . . . . .	8W-21
Sensor-Water In Fuel . . . . .	8W-30	Switch-Seat Belt-Driver . . . . .	8W-43
Sensors-Impact . . . . .	8W-43	Switch-Stop Lamp . . . . .	8W-33
Sensors-Oxygen . . . . .	8W-30	Switch-Sunroof . . . . .	8W-64
Sensors-Prop Shaft Speed . . . . .	8W-31	Switch-Tow/Haul Overdrive . . . . .	8W-31
Sensors-Wheel Speed . . . . .	8W-34, 35	Switch-Transfer Case Selector . . . . .	8W-31
Servo-Speed Control . . . . .	8W-33	Switch-Washer Fluid Level . . . . .	8W-53
Solenoid-Brake Transmission Shift		Switch-Winch . . . . .	8W-56
Interlock . . . . .	8W-31	Switch-Window/Door Lock-Driver . . . . .	8W-60, 61, 62
Solenoid-EVAP/Purge . . . . .	8W-30	Switches-Heated Seat . . . . .	8W-63
Solenoid-Radiator Fan . . . . .	8W-30	Switches-Power Window . . . . .	8W-60
Solenoid-Reverse Lock-Out . . . . .	8W-31	Switches-Remote Radio . . . . .	8W-47
Solenoid-Wastegate . . . . .	8W-30	Switches-Seat . . . . .	8W-63
Solenoids-Locker . . . . .	8W-31	Switches-Speed Control . . . . .	8W-33
Solenoids-Multiple Displacement . . . . .	8W-30	Throttle Body . . . . .	8W-30
Speakers . . . . .	8W-47	Transducer-A/C Pressure . . . . .	8W-42
Splices . . . . .	8W-70	Wiring-Trailer Tow . . . . .	8W-54
Starter . . . . .	8W-21		