

Sensor – Transmission Temperature (RC)



**SENSOR-
TRANSMISSION
TEMPERATURE
(RC)**

SENSOR-TRANSMISSION TEMPERATURE (RC) - (TRANSMISSION) 2 WAY

CAV	CIRCUIT	FUNCTION
1	T819 20YL/VT	TORQUE CONVERTER OIL TEMPERATURE SIGNAL
2	T820 20YL/WT	TORQUE CONVERTER OIL TEMPERATURE SIGNAL RETURN

