


Battery – Negative (Diesel Left Battery)




**BATTERY-
NEGATIVE
(DIESEL LEFT BATTERY)**

BATTERY-NEGATIVE (DIESEL LEFT BATTERY) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	Z3 8BK	GROUND
1	Z2 1BK	GROUND
1	Z1 10BK (5.9L)	GROUND
1	Z1 4BK (6.7L)	GROUND

Battery – Negative (Power Wagon)




**BATTERY-
NEGATIVE
(POWER WAGON)**

BATTERY-NEGATIVE (POWER WAGON) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	Z1 6BK	GROUND
1	Z2 6BK	GROUND
1	Z3 6BK	GROUND

Battery – Negative 1 (Gas Except Power Wagon)




**BATTERY-
NEGATIVE 1
(GAS EXCEPT POWER WAGON)**

BATTERY-NEGATIVE 1 (GAS EXCEPT POWER WAGON) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	Z1 6BK	GROUND
1	Z2 6BK	GROUND
1	Z1 4BK (5.7L EXCEPT HD/LD)	GROUND
1	Z2 4BK (5.7L EXCEPT HD/LD)	GROUND

Battery – Negative 2 (Gas Except Power Wagon)



**BATTERY-
NEGATIVE 2
(GAS EXCEPT POWER WAGON)**

BATTERY-NEGATIVE 2 (GAS EXCEPT POWER WAGON) - (BATTERY) 1 WAY

CAV	CIRCUIT	FUNCTION
1	Z3 6BK	GROUND