

Sensor – Transfer Case Position (MTC Except Power Wagon)




**SENSOR-
TRANSFER
CASE POSITION
(MTC EXCEPT
POWER WAGON)**

SENSOR-TRANSFER CASE POSITION (MTC EXCEPT POWER WAGON) - (TRANSMISSION) 2 WAY

CAV	CIRCUIT	FUNCTION
A	D201 20WT/DG (5.7L HD/6.7L DIESEL)	MODE SENSOR A
A	D201 18WT/DG (5.9L)	MODE SENSOR A
B	Z955 18BK (DIESEL)	GROUND
B	Z901 20BK (EXCEPT DIESEL)	GROUND

Sensor – Transfer Case Position (MTC Power Wagon)



**SENSOR-
TRANSFER
CASE
POSITION
(MTC POWER WAGON)**

SENSOR-TRANSFER CASE POSITION (MTC POWER WAGON) - BLACK (TRANSMISSION) 2 WAY

CAV	CIRCUIT	FUNCTION
1	D201 20WT/DG	MODE SENSOR A
2	G180 20VT/YL	SENSOR RETURN