


## Assembly – Transmission Solenoid C1 (RC)



**ASSEMBLY-  
TRANSMISSION  
SOLENOID C1  
(RC)**

ASSEMBLY-TRANSMISSION SOLENOID C1 (RC) - (TRANSMISSION) 10 WAY

CAV	CIRCUIT	FUNCTION
1	T806 20DG/WT	TRX-PRESS SW 7
2	T804 20YL/DB	TRX-PRESS SW 5
3	T54 20DG/OR	TRANSMISSION TEMPERATURE SENSOR SIGNAL
4	T817 20YL/BR	TRX-LINEAR SOL 3 (+)
5	T813 20DG/LG	TRX-LINEAR SOL 1 (+)
6	T807 20DG/WT	TRX-PRESS SW 8
7	T803 20DG/BR	TRX-PRESS SW 4
8	T820 20YL/WT	TORQUE CONVERTER OIL TEMPERATURE SIGNAL RETURN
9	T816 20YL/PK	TRX-LINEAR SOL 3 (-)
10	T812 20DG/TN	TRX-LINEAR SOL 1 (-)

