2008 MOPAR TRAILER TOW WIRING HARNESSES

These 4- way harnesses connect directly to the vehicle wiring harness and has provisions for: Tail lamps Brake & Turn Signal lamps Battery Ground

4 Way Harnesses				
PART #	VEHICLE	MYI	MYO	
82207253	DR/DH/D1	2002	2007	
82208434	HB	2004	2006	
82209773	HG/HB	2007	2008	
82208529	RS non stow n go	2004	2005	
82208957	RS w/ Stow n go flooring	2005	2007	

These 7- way harnesses connect directly to the vehicle wiring harness and has provisions for:

Tail lamps Battery Ground Trailer Brakes

Brake & Turn Signal lamps Back up Lamps **Battery Voltage**

7 WAY Harnesses				
PART #	VEHICLE	MYI	MYO	
82219771	DC	2007	2008	
82208432		2004	2006	
82209773	HG/HB	2007	2008	
82208490	RS non stow n go	2002	2006	
82208491	RS non stow n go	2005	2007	
82208957	RS w/ Stow n go flooring	2005	2007	
82210587	RT w/ Stow n go flooring	2008	2008	
82207253	DR/D1/DH	2002	2008	
82209045	Dakota	2005	2008	

These are the adaptors are the trailer side of the wiring harness:

82400554	7 Way	
82202089	4 Way	

These adaptors convert the vehicle 7- way to a 4-way or 6-way:

56019823	7 Way to 4 Way	
82401217	7-way to 6 way	







+ 🔍

IN

ø ÅLL **)**-

OUT