

8W-42 AIR CONDITIONING

Component	Page
Actuator-Blend Door	8W-42-5
Actuator-Blend Door-Driver	8W-42-4
Actuator-Blend Door-Passenger	8W-42-4
Actuator-Mode Door 1	8W-42-4, 5
Actuator-Mode Door 2	8W-42-4, 5
Actuator-Recirculation Door	8W-42-4, 5
Cluster	8W-42-2
Clutch-A/C Compressor	8W-42-6
Control-A/C-Heater	8W-42-2, 3, 4, 5
Data Link Connector	8W-42-3, 7
Fuse 12	8W-42-9, 10
Fuse 16	8W-42-6
Fuse 36	8W-42-3
G104	8W-42-2, 9, 10
G106	8W-42-9, 10
G107	8W-42-6
G110	8W-42-6
G120	8W-42-6

Component	Page
G201	8W-42-3
G203	8W-42-2
Module-Engine Control	8W-42-6, 8
Module-Integrated Power	8W-42-2, 3, 6, 9, 10
Module-Powertrain Control	8W-42-6, 7, 9, 10
Motor-Blower	8W-42-2
Motor-Condenser Fan	8W-42-9, 10
PTC No. 1	8W-42-6
Relay-Blower Motor	8W-42-2
Relay-Clutch-A/C Compressor	8W-42-6
Relay-Condenser Fan	8W-42-9, 10
Relay-Heated Mirror	8W-42-3
Resistor Block-Blower Motor	8W-42-2
Sensor-EVAPOrator Temperature	8W-42-3
Switch-Ignition	8W-42-2
Transducer-A/C Pressure	8W-42-7, 8

















