



8W-49 OVERHEAD CONSOLE

Component	Page
Assembly-Transmission Solenoid/TRS	8W-49-2
Cluster	8W-49-4, 5
Data Link Connector	8W-49-2
Fuse 23	8W-49-2
Fuse 28	8W-49-2
G201	8W-49-2
G203	8W-49-4, 5
Lamp-Dome-Rear	8W-49-4, 5
Lamp-Reading-Front	8W-49-4, 5
Lamp-Vanity-Left	8W-49-4
Lamp-Vanity-Right	8W-49-4

Component	Page
Mirror-Inside Rearview	8W-49-2
Module-Electronic Overhead	8W-49-2
Module-Front Control	8W-49-5
Module-Integrated Power	8W-49-2, 5
Module-Powertrain Control	8W-49-3
Motor-Sunroof	8W-49-4, 5
Sensor-Ambient Air Temperature	8W-49-3, 5
Sensor-Transmission Range	8W-49-2
Switch-Back Up Lamp	8W-49-2





SRT

