

WIRING DIAGRAMS

COMPONENT INDEX	8W-02-1
POWER DISTRIBUTION	8W-10-1
JUNCTION BLOCK	8W-12-1
INTEGRATED POWER MODULE	8W-13-1
GROUND DISTRIBUTION	8W-15-1
BUS COMMUNICATIONS	8W-18-1
CHARGING SYSTEM.....	8W-20-1
STARTING SYSTEM	8W-21-1
FUEL/IGNITION SYSTEM	8W-30-1
TRANSMISSION CONTROL SYSTEM	8W-31-1
VEHICLE SPEED CONTROL	8W-33-1
ALL WHEEL ANTILOCK BRAKES.....	8W-35-1
VEHICLE THEFT SECURITY SYSTEM.....	8W-39-1
INSTRUMENT CLUSTER.....	8W-40-1
HORN/CIGAR LIGHTER/POWER OUTLET. .	8W-41-1
AIR CONDITIONING-HEATER	8W-42-1
AIRBAG SYSTEM.....	8W-43-1
INTERIOR LIGHTING.....	8W-44-1
AUDIO SYSTEM	8W-47-1
REAR WINDOW DEFOGGER.....	8W-48-1
OVERHEAD CONSOLE.....	8W-49-1
FRONT LIGHTING	8W-50-1
REAR LIGHTING	8W-51-1
TURN SIGNALS.....	8W-52-1
WIPERS.....	8W-53-1
TRAILER TOW.....	8W-54-1
NAVIGATION/TELECOMMUNICATIONS	8W-55-1
CONVENIENCE SYSTEMS.....	8W-56-1
POWER WINDOWS.....	8W-60-1
POWER DOOR LOCKS	8W-61-1
POWER MIRRORS	8W-62-1
POWER SEATS	8W-63-1
POWER SUNROOF	8W-64-1
SPLICE INFORMATION	8W-70-1