

8W-50 FRONT LIGHTING

Component	Page	Component	Page
Cluster	8W-50-2	Lamp-Headlamp-Right	8W-50-4
Fuse 8	8W-50-3	Lamp-Park/Turn-Left Front	8W-50-3
Fuse 10	8W-50-3	Lamp-Park/Turn-Right Front	8W-50-3
Fuse 15	8W-50-2	Lamp-Side Marker-Left Front	8W-50-3
G112	8W-50-2, 3, 4	Lamp-Side Marker-Right Front	8W-50-3
G113	8W-50-2, 3, 4	Module-Front Control	8W-50-2, 3, 4
G208	8W-50-2	Module-Integrated Power	8W-50-2, 3
Lamp-Fog-Left Front	8W-50-2	Relay-Fog Lamp	8W-50-2
Lamp-Fog-Right Front	8W-50-2	Relay-Park Lamp	8W-50-3
Lamp-Headlamp-Left	8W-50-4	Switch-Headlamp	8W-50-2





