

## 8W-52 TURN SIGNALS

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Fuse 8 . . . . .	8W-52-2	Lamp-Park/Turn-Left Front . . . . .	8W-52-2
Fuse 10 . . . . .	8W-52-2	Lamp-Park/Turn-Right Front . . . . .	8W-52-2
G112 . . . . .	8W-52-2	Lamp-Tail/Stop/Turn-Left . . . . .	8W-52-2, 3
G113 . . . . .	8W-52-2	Lamp-Tail/Stop/Turn-Right . . . . .	8W-52-2, 3
G304 . . . . .	8W-52-3	Module-Front Control . . . . .	8W-52-2, 3
G306 . . . . .	8W-52-3	Module-Integrated Power . . . . .	8W-52-2, 3
Junction Block . . . . .	8W-52-2, 3	Relay-Park Lamp . . . . .	8W-52-2





