

8W-35 ALL WHEEL ANTILOCK BRAKES

Component	Page	Component	Page
Cluster	8W-35-4	Power Distribution Center	8W-35-2
Fuse 14	8W-35-2	Sensor-Brake Fluid Level	8W-35-2
Fuse 21	8W-35-2	Sensor-G	8W-35-3
Fuse 26	8W-35-2	Sensor-Wheel Speed-Abs-Left Front	8W-35-3
G114	8W-35-2	Sensor-Wheel Speed-Abs-Left Rear	8W-35-4
G208	8W-35-4	Sensor-Wheel Speed-Abs-Rear	8W-35-3
Junction Block	8W-35-2	Sensor-Wheel Speed-Abs-Right Front	8W-35-3
Module-Antilock Brakes	8W-35-2, 3, 4	Sensor-Wheel Speed-Abs-Right Rear	8W-35-4
Module-Powertrain Control	8W-35-2	Switch-Traction Control	8W-35-4





