


## 8W-33 VEHICLE SPEED CONTROL

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Brake Lamp Switch . . . . .	8W-33-3	Powertrain Control Module . . . . .	8W-33-2, 3
Clockspring . . . . .	8W-33-2, 4	Right Speed Control Switch . . . . .	8W-33-2, 4
Engine Control Module . . . . .	8W-33-4	Speed Control Servo . . . . .	8W-33-3
G101 . . . . .	8W-33-3	Transmission Control Module . . . . .	8W-33-4
Input Speed Sensor . . . . .	8W-33-2	Transmission Range Sensor . . . . .	8W-33-4
Left Speed Control Switch . . . . .	8W-33-2, 4	Vehicle Speed Sensor . . . . .	8W-33-2
Output Speed Sensor . . . . .	8W-33-2		



**GAS**

