

8W-50 FRONT LIGHTING

Component	Page	Component	Page
Body Control Module	8W-50-2, 4, 5	Left Headlamp	8W-50-3
Front Control Module	8W-50-3, 4, 6, 7, 8, 9, 10	Left Headlamp Leveling Motor	8W-50-6, 9
Front Fog Lamp Relay	8W-50-10	Left High Beam Lamp	8W-50-6, 7
Fuse 1	8W-50-10	Left Low Beam Lamp	8W-50-7
Fuse 2	8W-50-4, 6	Left Park Lamp	8W-50-6, 7
Fuse 3	8W-50-4, 6	Multi-Function Switch	8W-50-5
G102	8W-50-4, 6, 10	Park Lamp Relay	8W-50-4, 6
G200	8W-50-2, 9	Right Fog Lamp	8W-50-10
G300	8W-50-3	Right Front Park/Turn Signal Lamp	8W-50-4
Headlamp Switch	8W-50-2, 9	Right Headlamp	8W-50-3
Integrated Power		Right Headlamp Leveling Motor	8W-50-6, 9
Module	8W-50-3, 4, 5, 6, 7, 8, 9, 10	Right High Beam Lamp	8W-50-6, 8
Left Fog Lamp	8W-50-10	Right Low Beam Lamp	8W-50-8
Left Front Park/Turn Signal Lamp	8W-50-4	Right Park Lamp	8W-50-6, 8













