




8W-43 OCCUPANT RESTRAINT SYSTEM

Component	Page	Component	Page
Belt Tension Sensor	8W-43-8	Left Side Impact Sensor 1	8W-43-6
Clockspring	8W-43-4	Left Side Impact Sensor 2	8W-43-6
Driver Airbag Squib 1	8W-43-4	Left Side Impact Sensor 3	8W-43-6
Driver Airbag Squib 2	8W-43-4	Occupant Classification Module	8W-43-2, 8
Driver Knee Blocker Airbag Squib	8W-43-4	Occupant Restraint	
Driver Seat Belt Switch	8W-43-3	Controller	8W-43-2, 3, 4, 5, 6, 7, 8
Driver Seat Belt Tensioner	8W-43-3	Passenger Airbag	8W-43-5
Front Control Module	8W-43-2, 8	Passenger Airbag On/Off Indicator Lamp ..	8W-43-2
G200	8W-43-2	Passenger Seat Belt Switch	8W-43-5
G201	8W-43-2	Passenger Seat Belt Tensioner	8W-43-5
G301	8W-43-8	Passenger Seat Weight Sensor	8W-43-8
Instrument Cluster	8W-43-2	Right Curtain Airbag Squib	8W-43-7
Instrument Panel Switch Bank	8W-43-2	Right Front Impact Sensor	8W-43-7
Integrated Power Module	8W-43-2, 8	Right Side Impact Sensor 1	8W-43-7
Left Curtain Airbag Squib	8W-43-6	Right Side Impact Sensor 2	8W-43-7
Left Front Impact Sensor	8W-43-6	Right Side Impact Sensor 3	8W-43-7







- ▼ OCCUPANT SENSING
- ▼▼ EXCEPT OCCUPANT SENSING
- △ EXCEPT EXPORT
- △△ EXPORT

