




8W-45 BODY CONTROL MODULE


Component	Page	Component	Page
A/C-Heater Control	8W-45-16, 19	License Lamp	8W-45-8
Auto Temp Control	8W-45-16, 19	Liftgate Ajar Switch	8W-45-12
Body Control Module	8W-45-2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15, 16, 17, 18, 19, 20	Liftgate Cinch/Release Motor	8W-45-12
Clockspring	8W-45-17	Memory Set Switch	8W-45-4
Controller Antilock Brake	8W-45-13	Message Center	8W-45-18
Driver Door Courtesy Lamp	8W-45-15	Multi-Function Switch	8W-45-16
Driver Door Lock Switch	8W-45-12, 15	Overhead Console	8W-45-4, 11
Driver Heated Seat Module	8W-45-11	Passenger Door Courtesy Lamp	8W-45-15
Floor Console Lamp	8W-45-13	Passenger Door Lock Switch	8W-45-12, 15
Front Control Module	8W-45-3	Passenger Folding Mirror Relay	8W-45-20
Front Reading Lamps/Switch	8W-45-13, 15	Passenger Heated Seat Module	8W-45-11
Fuel Pump Module	8W-45-15	Power Folding Mirror Switch	8W-45-20
Fuse 14	8W-45-3	Power Liftgate Module	8W-45-8, 12
Fuse 19	8W-45-2	Radio	8W-45-17
Fuse 24	8W-45-2	Rear Auto Temp Control Switch	8W-45-10, 19
G301	8W-45-2, 8	Rear Blower Rear Control Switch	8W-45-10
Headlamp Switch	8W-45-11, 16, 20	Rear Dome Lamp	8W-45-9
Hood Ajar Switch	8W-45-12	Rear View Mirror	8W-45-11
Ignition Switch	8W-45-3	Rear Wiper Motor	8W-45-8
Instrument Cluster	8W-45-2, 16, 18, 19	Right B-Pillar Switch	8W-45-9
Instrument Panel Switch		Right Cylinder Lock Switch	8W-45-10
Bank	8W-45-10, 11, 17, 19	Right Front Door Ajar Switch	8W-45-9
Integrated Power Module	8W-45-2, 3, 5, 6, 13	Right Front Door Lock Motor/Ajar Switch	8W-45-7, 9
Left B-Pillar Switch	8W-45-9	Right Liftgate Flood Lamp	8W-45-12
Left Cylinder Lock Switch	8W-45-10	Right Mid Reading Lamp	8W-45-9, 14
Left Front Door Ajar Switch	8W-45-9	Right Power Mirror	8W-45-20
Left Front Door Lock Motor/Ajar Switch	8W-45-7, 9	Right Rear Lamp Assembly	8W-45-5, 6
Left Liftgate Flood Lamp	8W-45-12	Right Rear Reading Lamp	8W-45-9, 14
Left Mid Reading Lamp	8W-45-9, 14	Right Remote Radio Switch	8W-45-17
Left Power Mirror	8W-45-20	Right Repeater Lamp	8W-45-20
Left Rear Lamp Assembly	8W-45-5, 6	Right Sliding Door Control Module	8W-45-8, 10
Left Rear Reading Lamp	8W-45-9, 14	Right Sliding Door Lock Motor	8W-45-7
Left Remote Radio Switch	8W-45-17	Right Sliding Door Lock Motor/Ajar Switch	8W-45-7, 8
Left Repeater Lamp	8W-45-20	Right Visor/Vanity Lamp	8W-45-13
Left Sliding Door Control Module	8W-45-8, 10	Sentry Key Remote Entry Module	8W-45-3
Left Sliding Door Lock Motor	8W-45-7	Thatcham Alarm Module	8W-45-10
Left Sliding Door Lock Motor/Ajar Switch	8W-45-7, 8	Traction Control Switch	8W-45-17
Left Visor/Vanity Lamp	8W-45-13	Trailer Tow Connector	8W-45-5








▲ EXCEPT EXPORT
 • LHD
 •• RHD





























▣ ASSY. PLANT EVAC & FILL

◇◇◇ ABS







● AUTO HEADLAMPS
◆◆◆ HIGHLINE



**** REMOTE AUDIO
 ◇◇◇ ABS
 ▲ HEATED SEATS
 ▲▲ EXCEPT HEATED SEATS





△ HEATED SEATS

