



## 8W-52 TURN SIGNALS


<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Body Control Module . . . . .	8W-52-2, 3, 4, 5	Left Rear Lamp Assembly . . . . .	8W-52-4
Fuse 24 . . . . .	8W-52-5	Left Repeater Lamp . . . . .	8W-52-5
G102 . . . . .	8W-52-2	Left Turn Signal Lamp . . . . .	8W-52-3
G200 . . . . .	8W-52-2, 3	Multi-Function Switch . . . . .	8W-52-2, 3
G302 . . . . .	8W-52-4	Right Front Park/Turn Signal Lamp . . . . .	8W-52-2
Instrument Cluster . . . . .	8W-52-5	Right Rear Lamp Assembly . . . . .	8W-52-4
Instrument Panel Switch Bank . . . . .	8W-52-2, 3	Right Repeater Lamp . . . . .	8W-52-5
Integrated Power Module . . . . .	8W-52-2, 3, 5	Right Turn Signal Lamp . . . . .	8W-52-3
Left Front Park/Turn Signal Lamp . . . . .	8W-52-2	Trailer Tow Connector . . . . .	8W-52-4




**MULTI-FUNCTION SWITCH**  
 0 OFF  
 1 RIGHT  
 2 LEFT




**BODY CONTROL MODULE**  
 (8W-45-10)  
 (8W-45-16)




**INSTRUMENT PANEL SWITCH BANK**  
 HAZARD SWITCH  
 0 OFF  
 1 ON




**INTEGRATED POWER MODULE**  
 (8W-10-3)  
 (8W-10-5)



**LEFT FRONT PARK/TURN SIGNAL LAMP**  
 (8W-50-4)




**RIGHT FRONT PARK/TURN SIGNAL LAMP**  
 (8W-50-4)




△ HEATED SEATS  
 △△ EXCEPT HEATED SEATS








**MULTI-FUNCTION SWITCH**  
 0 OFF  
 1 RIGHT  
 2 LEFT




**BODY CONTROL MODULE**  
 (8W-45-6)  
 (8W-45-10)  
 (8W-45-16)




**INTEGRATED POWER MODULE**  
 (8W-10-3)  
 (8W-10-4)  
 (8W-10-5)



**INSTRUMENT PANEL SWITCH BANK**  
 HAZARD SWITCH  
 0 OFF  
 1 ON



**LEFT TURN SIGNAL LAMP**



**RIGHT TURN SIGNAL LAMP**

△ HEATED SEATS  
 △△ EXCEPT HEATED SEATS

