

## 8W-35 ANTILOCK BRAKES

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Body Control Module . . . . .	8W-35-2	G200 . . . . .	8W-35-2
Brake Fluid Level Switch . . . . .	8W-35-3	G300 . . . . .	8W-35-3
Brake Lamp Switch . . . . .	8W-35-3	Integrated Power Module . . . . .	8W-35-2, 3
Clutch Pedal Interlock Switch . . . . .	8W-35-3	Left Front Wheel Speed Sensor . . . . .	8W-35-4
Controller Antilock Brake . . . . .	8W-35-2, 3, 4	Left Rear Wheel Speed Sensor . . . . .	8W-35-4
Engine Control Module . . . . .	8W-35-3	Powertrain Control Module . . . . .	8W-35-3
Front Control Module . . . . .	8W-35-3	Right Front Wheel Speed Sensor . . . . .	8W-35-4
Fuse 9 . . . . .	8W-35-2	Right Rear Wheel Speed Sensor . . . . .	8W-35-4
Fuse 21 . . . . .	8W-35-2	Traction Control Switch . . . . .	8W-35-2
Fuse 26 . . . . .	8W-35-3	Transmission Control Module . . . . .	8W-35-3
G100 . . . . .	8W-35-2		





