

## 8W-41 HORN/CIGAR LIGHTER/POWER OUTLET

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Accessory Relay . . . . .	8W-41-3, 4	G200 . . . . .	8W-41-2, 3, 4
Clockspring . . . . .	8W-41-2	G302 . . . . .	8W-41-3, 4
Data Link Connector . . . . .	8W-41-4	High Note Horn . . . . .	8W-41-2
Floor Console Lamp . . . . .	8W-41-4	Horn Relay . . . . .	8W-41-2
Floor Console Power Outlet . . . . .	8W-41-4	Horn Switch . . . . .	8W-41-2
Front Cigar Lighter . . . . .	8W-41-3	Integrated Power Module . . . . .	8W-41-2, 3, 4
Front Control Module . . . . .	8W-41-2, 3, 4	Power Outlet . . . . .	8W-41-4
Fuse 5 . . . . .	8W-41-3	PTC 7 . . . . .	8W-41-4
Fuse 6 . . . . .	8W-41-3, 4	Radio . . . . .	8W-41-3
Fuse 8 . . . . .	8W-41-2	Rear Power Outlet . . . . .	8W-41-3
G102 . . . . .	8W-41-2		





