

## 8W-44 INTERIOR LIGHTING

<b>Component</b>	<b>Page</b>
Electronics . . . . .	8W-44-4
Fuse 11 . . . . .	8W-44-3
Fuse 16 . . . . .	8W-44-4
G104 . . . . .	8W-44-3
G203 . . . . .	8W-44-2, 4
Lamp-Center Bezel . . . . .	8W-44-4
Lamp-Dome-Rear . . . . .	8W-44-2
Lamp-Glove Box . . . . .	8W-44-2
Lamp-High Mounted Stop/Cargo . . . . .	8W-44-2
Lamp-Reading-Front . . . . .	8W-44-2

<b>Component</b>	<b>Page</b>
Lamp-Underhood . . . . .	8W-44-3
Lamp-Vanity-Left . . . . .	8W-44-2
Lamp-Vanity-Right . . . . .	8W-44-2
Latch-Door-Driver . . . . .	8W-44-3
Latch-Door-Left Rear . . . . .	8W-44-3
Latch-Door-Passenger . . . . .	8W-44-4
Latch-Door-Right Rear . . . . .	8W-44-4
Module-Totally Integrated Power . . . . .	8W-44-3, 4
Motor/Module-Sunroof . . . . .	8W-44-2





