

8W-60 POWER WINDOWS

| Component | Page |
|--|-------------|
| Circuit Breaker-Window/Door Lock | 8W-60-2, 3 |
| Cluster | 8W-60-2 |
| G300 | 8W-60-2, 3 |
| G301 | 8W-60-2, 3 |
| Motor-Window-Left Front | 8W-60-2, 3 |
| Motor-Window-Left Rear | 8W-60-4 |
| Motor-Window-Right Front | 8W-60-2, 3 |
| Motor-Window-Right Rear | 8W-60-4 |

| Component | Page |
|---|-------------|
| Switch-Power Window-Left Rear | 8W-60-4 |
| Switch-Power Window-Right Rear | 8W-60-4 |
| Switch-Window/Door Lock-Driver | 8W-60-2 |
| Switch-Window/Door Lock-Driver Express | 8W-60-3, 4 |
| Switch-Window/Door Lock-Passenger . . . | 8W-60-2, 3 |





