


8W-35 ALL WHEEL ANTILOCK BRAKES

Component	Page	Component	Page
Cluster	8W-35-4	Power Distribution Center	8W-35-2
Fuse 14	8W-35-2	Relay-Stop Lamp Inhibit	8W-35-2
Fuse 21	8W-35-2	Sensor-Brake Fluid Level	8W-35-2
Fuse 26	8W-35-2, 5	Sensor-Dynamics	8W-35-5
G114	8W-35-2	Sensor-Steering Angle	8W-35-5
G207	8W-35-5	Sensor-Vacuum Pressure	8W-35-3
G208	8W-35-4, 5	Sensor-Wheel Speed-ABS-Left Front	8W-35-3
Junction Block	8W-35-2, 5	Sensor-Wheel Speed-ABS-Left Rear	8W-35-4
Module-Antilock Brakes	8W-35-2, 3, 4, 5	Sensor-Wheel Speed-ABS-Right Front	8W-35-3
Module-Front Control	8W-35-2	Sensor-Wheel Speed-ABS-Right Rear	8W-35-4
Module-Powertrain Control	8W-35-2	Switch-Traction Control	8W-35-4



※ NOTE: D64, D65 CIRCUITS ARE TWISTED PAIR

