

8W-41 HORN/CIGAR LIGHTER/POWER OUTLET

Component	Page	Component	Page
Clockspring	8W-41-2	Horn-No. 2	8W-41-2
Cluster	8W-41-2	Junction Block	8W-41-3
Fuse 3	8W-41-3	Module-Front Control	8W-41-2
Fuse 16	8W-41-2	Module-Integrated Power	8W-41-2
Fuse 35	8W-41-3	Power Outlet-Console	8W-41-3
G112	8W-41-2	Power Outlet-Instrument Panel	8W-41-3
G113	8W-41-2	Power Outlet-Rear	8W-41-3
G207	8W-41-3	Power Outlet-Rear Seat	8W-41-3
G304	8W-41-3	Relay-Accessory Delay	8W-41-3
G306	8W-41-3	Relay-Horn	8W-41-2
Horn-No. 1	8W-41-2	Switch-Horn	8W-41-2



