



8W-18 BUS COMMUNICATIONS


Component	Page
Amplifier-Radio	8W-18-3, 5
Cluster	8W-18-3, 5
Control-A/C-Heater	8W-18-3, 5
Data Link Connector	8W-18-2
Fuse 14	8W-18-2
G208	8W-18-2
Junction Block	8W-18-2, 3, 4, 5, 6, 7
Media System-Monitor/Dvd	8W-18-4, 6
Module-Antilock Brakes	8W-18-7
Module-Door-Driver	8W-18-4, 6
Module-Door-Passenger	8W-18-4, 6
Module-Electronic Overhead	8W-18-4, 6


Component	Page
Module-Front Control	8W-18-2, 4, 6, 7
Module-Hands Free	8W-18-3, 5
Module-Heated Seat	8W-18-4, 6
Module-Occupant Restraint Controller . .	8W-18-3, 5
Module-Park Assist	8W-18-4, 6
Module-Power Liftgate	8W-18-4, 6
Module-Powertrain Control	8W-18-7
Module-Seat Memory	8W-18-4, 6
Module-Wireless Control	8W-18-3, 5
Radio	8W-18-3, 5
Receiver-Satellite	8W-18-4, 6
Sensor-Steering Angle	8W-18-7





□ ATC
□ MTC
※ NOTE: D54, D55 CIRCUITS ARE TWISTED PAIR





□ ATC
 □□ MTC
 ✕ NOTE: D54, D55 CIRCUITS ARE TWISTED PAIR

