

8W-60 POWER WINDOWS

Component	Page
Circuit Breaker-Power Window	8W-60-2
G302	8W-60-2, 3, 4, 5
Motor-Power Window Driver	8W-60-2
Motor-Power Window-Left Rear	8W-60-5
Motor-Power Window-Passenger	8W-60-3
Motor-Power Window-Right Rear	8W-60-4
Relay-Ignition Run-Acc	8W-60-2

Component	Page
Switch-Ignition	8W-60-2
Switch-Power Window-Left Rear	8W-60-5
Switch-Power Window-Passenger	8W-60-3
Switch-Power Window-Right Rear	8W-60-4
Switch-Window/Door Lock-Driver . .	8W-60-2, 3, 4, 5









