

## 8W-52 TURN SIGNALS

<b>Component</b>	<b>Page</b>	<b>Component</b>	<b>Page</b>
Cluster . . . . .	8W-52-3	Lamp-Park/Turn-Right Front . . . . .	8W-52-2
Fuse 43 . . . . .	8W-52-2	Lamp-Tail/Stop/Turn-Left . . . . .	8W-52-2, 3
Fuse 44 . . . . .	8W-52-2	Lamp-Tail/Stop/Turn-Right . . . . .	8W-52-2, 3
Fuse 51 . . . . .	8W-52-2	Module-Front Control . . . . .	8W-52-2, 3
Fuse 55 . . . . .	8W-52-3	Module-Integrated Power . . . . .	8W-52-2, 3
G100 . . . . .	8W-52-3	Relay-Park Lamp . . . . .	8W-52-2
G101 . . . . .	8W-52-2	Switch-Multifunction . . . . .	8W-52-3
G103 . . . . .	8W-52-2		
Lamp-Park/Turn-Left Front . . . . .	8W-52-2		





